

BM 150X Drum & Disc



BM 150X Drum & Disc

**THE WORLD'S
FAVOURITE
INDIAN**

Spare Parts Catalogue



Bajaj Auto Limited
Akurdi Pune 411 035 India
www.bajajauto.com

Notice

All information contained in this manual is based on the latest product information at the time of publication. Bajaj Auto Limited accepts no liability for any inaccuracies or omissions in this publication, although every possible care has been taken to make it as complete and accurate as possible. All procedures and specifications subject to change without prior notice. The right is reserved to make such changes at any time without prior notice and without incurring an obligation to make such changes to product manufactured previously. Contact your authorized Bajaj Dealer for the latest information on product improvements incorporated after this manual was issued.

REV. APRIL. 2022

Foreword

We have pleasure in presenting the Spare Parts Catalogue for 'BOXER 150X DRUM & DISC OFF ROADER' Motorcycle. This catalogue has been specially designed to assist you in selecting the correct parts for procurement to maintain 100% availability.

The Bajaj spares are subjected to the stringent quality control standards to ensure longer life of the vehicle. It is therefore necessary that only the Genuine Bajaj Spares are used.

In a continual effort to improve Performance and Efficiency of the vehicles, Specifications, Diagrams, Illustrations and Part Numbers can change without notice. Consequently, the description in this Spare Parts Catalogue cannot therefore be final and binding on us.

The modifications / alterations which are carried out after the issue of this catalogue, will be conveyed to you through our Service Circulars. You are requested to make necessary corrections in the Parts Catalogue as per the circulars so as to keep your catalogue up-to-date. This will ensure the appropriate and speedy delivery of the Spare Parts as the order placed will bear the latest part numbers.

In case, if you need any technical assistance contact the concerned Regional Office or write to us on the following address :

Bajaj Auto Limited
Spares - International Business
Akurdi, Pune 411 035 India

Instructions

1. How to Read the Catalogue : Open the catalogue and from the pictorial index locate the group in which the part you want to find is present. Turn over to the concerned page number (as given by pictorial index). Now find out the figure of the part you wish to order. Write down the part number against that particular figure number from the text.

In case, if you have the part number and you need the other details, the part index can be used. The part index (at the end of the catalogue) will give you the figure and page number of the part you wish to order.

2. How to Order Spare Parts : The part number and the description of the part required should be invariably mentioned in the order as per the catalogue text.

The latest part number as conveyed through our service circulars should only appear on the order. In case of ordering painted components, colour shade of the components should be mentioned.

The quantity shown against the part number is the quantity per vehicle for that group so that particular quantity should be multiplied by the number of sets required.

3. Part Number System : We have used 8 digit system for part numbers. The model or hardware item is indicated by first two digits or alphanumeric, the next two or four digits indicate main group and the last four or two digits indicate serial number in main group or serial number or subgroup of fastener respectively. Thus the part numbers will be indicated by 2-2-4 or 2-4-2 digit system. Understanding this system will enable you to identify the spare parts easily.

4. Abbreviations : The following abbreviations are used in this catalogue.

Assly	Assembly	V	Volts
N.I.	Not illustrated	W	Watts
C'case	Crankcase	Accl.	Accelerator
Cyl	Cylinder	Comp.	Complete
O/s	Over size	Fr.	Front
Rr.	Rear	Std.	Standard
L	Length	A/t.	Alternate
R.H.	Right hand	L.H.	Left hand
Hex.	Hexagonal	AR	As required





Index

Plate No.	Description	Page No.
1	Cover Cylinder Head	2
2	Cylinder Head	4
3	Valve	6
4	Camshaft / Tensioner	8
5	Cylinder & Piston	10
6	Crankshaft	12
7	Transmission - 4 Gear	14
8	Transmission - UG 5 Gear	16
9	Change Drum / Shift Fork	18
10	Gear Change Mechanism	20
11	Engine Assembly / Crankcase RH	22
12	Crankcase LH	24
13	Cover RH	26
14	Cover Magneto	28
15	Clutch	30
16	Kick Starter Mechanism	32
17	Carburettor	34
18	Air Cleaner Complete	36
19	Silencer Assembly	38
20	Oil Pump	40
21	Starter Assembly	42
22	Magneto, C.D.I. & H.T. Coil	44
23	Seat Assembly	46
24	Engine Mountings	48
25	Frame and Frame Fittings	50
26	Swing Arm / Rear Shock Absorber	52
27	Rider Foot Rest / Pillion Foot Rest	54





Index

Plate No.	Description	Page No.
28	Mudguard - Front & Rear	56
29	Stand Assembly	58
30	Tube / Tyre / Rim	60
31	Front Hub - For Drum Brake	62
32	Front Hub - For Disc Brake	64
33	Front Master Cylinder	66
34	Front Disc Brake - Caliper	68
35	Rear Hub	70
36	Rear Brake Pedal	72
37	Handle Bar	74,76
38	Front Fork	78,80
39	Fuel Tank, Cap Tank & Gauge Fuel	82
40	Fittings - Fuel Tank, Side Cover & Cover Seat	84
41	Meter Assembly	86
42	Control Cables	88
43	Chain Case	90
44	Head Lamp & Fairing	92
45	Indicator Light Assembly	94
46	Tail Lamp Assembly / Front Number Plate	96
47	Electrical Equipments	98
48	Tool Kit	100
49	Accessories	102
50	Painted Parts & Decals	104
	Kits List	105 to 108
	Amendment Sheet (Parts Added & Deleted)	109 to 110
	Part Index	111 to 122

Pictorial Index

PLATE NO. : 1 COVER CYLINDER HEAD	PAGE NO. 2	PLATE NO. : 2 CYLINDER HEAD	PAGE NO. 4
			
PLATE NO. : 3 VALVE	PAGE NO. 6	PLATE NO. : 4 CAMSHAFT / TENSIONER	PAGE NO. 8
			

Pictorial Index

PLATE NO. : 5 CYLINDER AND PISTON	PAGE NO. 10	PLATE NO. : 6 CRANKSHAFT	PAGE NO. 12
			
PLATE NO. : 7 TRANSMISSION - 4 Gear	PAGE NO. 14	PLATE NO. : 8 TRANSMISSION - UG 5 GEAR	PAGE NO. 16
			

Pictorial Index

PLATE NO. : 9	PAGE NO.
CHANGE DRUM / SHIFT FORK	18




PLATE NO. : 10	PAGE NO.
GEAR CHANGE MECHANISM	20




PLATE NO. : 11	PAGE NO.
ENGINE ASSLY / CRANKCASE RH	22





PLATE NO. : 12	PAGE NO.
CRANKCASE LH	24



Pictorial Index

PLATE NO. : 13	PAGE NO.
COVER RH	26




PLATE NO. : 14	PAGE NO.
COVER MAGNETO	28




PLATE NO. : 15	PAGE NO.
CLUTCH	30





PLATE NO. : 16	PAGE NO.
KICK STARTER MECHANISM	32



Pictorial Index

PLATE NO. : 17
CARBURETTOR

PAGE NO.
34




PLATE NO. : 18
AIR CLEANER COMPLETE

PAGE NO.
36




PLATE NO. : 19
SILENCER ASSEMBLY

PAGE NO.
38





PLATE NO. : 20
OIL PUMP

PAGE NO.
40



Pictorial Index

PLATE NO. : 21
STARTER ASSEMBLY

PAGE NO.
42




PLATE NO. : 22
MAGNETO, CDI & H.T. COIL

PAGE NO.
44




PLATE NO. : 23
SEAT ASSEMBLY

PAGE NO.
46





PLATE NO. : 24
ENGINE MOUNTINGS

PAGE NO.
48



Pictorial Index

PLATE NO. : 25 FRAME & FRAME FITTINGS	PAGE NO. 50
--	----------------




PLATE NO. : 26 SWING ARM / REAR SHOCK ABSORBER	PAGE NO. 52
--	----------------




PLATE NO. : 27 RIDER FOOT REST / PILLION FOOT REST	PAGE NO. 54
--	----------------





PLATE NO. : 28 MUDGUARD - FRONT & REAR	PAGE NO. 56
---	----------------



Pictorial Index

PLATE NO. : 29 STAND ASSEMBLY	PAGE NO. 58
----------------------------------	----------------




PLATE NO. : 30 TUBE / TYRE / RIM	PAGE NO. 60
-------------------------------------	----------------




PLATE NO. : 31 FRONT HUB - FOR DRUM BRAKE	PAGE NO. 62
--	----------------





PLATE NO. : 32 FRONT HUB - FOR DISC BRAKE	PAGE NO. 64
--	----------------



Pictorial Index





PLATE NO. : 33 FRONT MASTER CYLINDER	PAGE NO. 66	PLATE NO. : 34 FRONT DISC BRAKE - CALIPER	PAGE NO. 68
		 - SEAL - SCRAPER RING - INSULATOR - DUST COVER - BLEEDER CAP - PISTON - BLEEDER SCREW	

PLATE NO. : 35 REAR HUB	PAGE NO. 70	PLATE NO. : 36 REAR BRAKE PEDAL	PAGE NO. 72
			

Pictorial Index













PLATE NO. : 37 HANDLE BAR	PAGE NO. 74,76	PLATE NO. : 38 FRONT FORK	PAGE NO. 78,80
			

PLATE NO. : 39 FUEL TANK, CAP TANK & GAUGE FUEL	PAGE NO. 82	PLATE NO. : 40 FITTING - FUEL TANK, SIDE COVER & COVER SEAT	PAGE NO. 84
			


Pictorial Index

PLATE NO. : 41 METER ASSEMBLY	PAGE NO. 86	PLATE NO. : 42 CONTROL CABLES	PAGE NO. 88
			
PLATE NO. : 43 CHAIN CASE	PAGE NO. 90	PLATE NO. : 44 HEAD LAMP & FAIRING	PAGE NO. 92
			

Pictorial Index


PLATE NO. : 45 INDICATOR LIGHT ASSEMBLY	PAGE NO. 94	PLATE NO. : 46 TAIL LAMP ASSEMBLY / FRONT NUMBER PLATE	PAGE NO. 96
			
PLATE NO. : 47 ELECTRICAL EQUIPMENTS	PAGE NO. 98	PLATE NO. : 48 TOOL KIT	PAGE NO. 100
			

Pictorial Index

PLATE NO. : 49 ACCESSORIES	PAGE NO. 102	PLATE NO. : 50 PAINTED PARTS & DECALS	PAGE NO. 104
			
PLATE NO. :	PAGE NO.	PLATE NO. :	PAGE NO.


Pictorial Index

PLATE NO. :	PAGE NO.	PLATE NO. :	PAGE NO.
PLATE NO. :	PAGE NO.	PLATE NO. :	PAGE NO.




Cover Cylinder Head

No.	Part No.	Description	Drum	Disc	Remarks
1	JZ 5110 21	Cover Cylinder Head Assembly	1	1	
2	59 0400 38	Bolt	4	4	
3	JD 5110 10	Gasket Head Cover	1	1	
4	JA 5110 08	Bolt Head Mounting	4	4	
5	PA 5110 39	Plate Cylinder Head	1	1	
6	JA 5110 11	Hose Breather	1	1	
7	DP 1210 25	Clamp	3	3	
8	PF 5110 21	Flange Bolt	1	1	




Cylinder Head

No.	Part No.	Description	Drum	Disc	Remarks
1	36 PF00 01	Kit Assembly Cylinder Head	1	1	UG 5 Gear
	36 PF01 60	Kit Cylinder Head Black	1	1	
2	JA 5110 28	Stud	2	2	
3	JZ 5110 16	Gasket Cylinder Head	1	1	
4	PF 5814 01	Intake Manifold	1	1	
5	JA 5814 06	Bolt Flange	2	2	
6	PF 5814 02	Sleeve (Carb - Duct Rubber)	1	1	
7	DH 1210 38	Clamp	2	2	
8	39 2539 21	'O' Ring (Intake Pipe)	1	1	




Valve

No.	Part No.	Description	Drum	Disc	Remarks
1	JA 5112 11	Shaft Rocker Arm	2	2	
2	JZ 5112 03	Rocker Arm with Roller	2	2	
3	DG 1010 29	Cotter Valve (Collet)	4	4	
4	36 JZ00 01	Valve Kit	1	1	
5	36 JZ00 04	Valve Repair Kit	1	1	
6	39 2017 19	Seal Valve Stem	2	2	




Camshaft / Tensioner

No.	Part No.	Description	Drum	Disc	Remarks
1	JZ 5110 04	Camshaft Complete	1	1	
2	JA 5112 16	Spacer Cam Sprocket	1	1	
3	PD 5112 29	Sprocket Camshaft	1	1	
4	DK 1013 86	Precoated Soc Hd Cap Bolt M8x40	1	1	
5	DH 1010 48	Special Washer Cam Shaft	1	1	
6	36 JE00 03	Guide Chain Kit	1	1	
7	DH 1013 92	Cam chain Tensioner Pivot Bolt	1	1	
8	JV 5210 03	Adjuster Chain Silver	1	1	
9	CS 1011 28	Gasket	1	1	
10	DD 1010 62	Bolt M6 Chain Tensioner	1	1	
11	39 1673 04	Bolt M6 X 20 Silver	2	2	
12	39 0594 17	Circlip for Camshaft	1	1	
13	39 2669 21	'O' Ring (Tensioner)	1	1	
14	DS 1099 05	Cam Chain (94 Link)	1	1	
15	39 1880 20	Bearing Ball - Small 15 X 32 X 9	1	1	
16	39 2683 20	Bearing Ball - Big 17 X 35 X 10	1	1	




Cylinder and Piston

No.	Part No.	Description	Drum	Disc	Remarks
1	JH 5210 07	Gasket Block Cylinder	1	1	UG 5 Gear
2	39 1000 06	Dowel Pin	2	2	
3	36 PF01 16	Piston Ring Set	1	1	
4	DP 1011 65	Ring Snap	2	2	
5	36 PF00 02	Kit Cylinder Block & Piston Assembly	1	1	
	36 PF01 59	Kit Cylinder Block & Piston Black	1	1	
6	JA 5210 15	Damper Cylinder Block	3	3	




Crankshaft

No.	Part No.	Description	Drum	Disc	Remarks
1	59 1500 14	Flange Nut	2	2	UG 5 Gear
2A	59 1200 03	Belleville Washer	2	2	
2B	59 1100 08	Plain Washer	1	1	
3	31 1011 73	Key Woodruff	1	1	
4	PF 5310 00	Assembly Crankshaft	1	1	
	PF 5310 33	Crankshaft Assembly	1	1	
5	JE 5310 01	Ball Bearing 56 X 22 X 16	2	2	
6	DS 1011 54	Parallel Key	1	1	
7	36 JZ00 03	Set Primary Drive / Driven	1	1	
8	JA 531012	Spring	1	1	
9	JA 5310 15	Pin Crank Shaft Plunger	1	1	UG 5 Gear
10	JB 5310 21	Plunger Oil Crank Shaft	1	1	
11	36 PF01 07	kit Connecting Rod	1	1	
12	JD 5310 04	Spacer Crankshaft	1	1	



Transmission - 4 Gear


No.	Part No.	Description	Drum	Disc	Remarks
1	PF 5510 02	Shaft Input	1	1	
2	PF 5512 02	Gear 4th Drive	1	1	
3	39 0987 17	Ring Snap (17.2 X 20.5 X 1.5)	5	5	
4	JA 5510 02	Spline Washer (17.2 X 20.5 X 1.5)	3	3	
5	PF 5512 01	Gear 3rd Drive	1	1	
6	PF 5512 00	Gear 2nd Drive	1	1	
7	JA 5510 04	Washer Thrust 2nd Drive	1	1	
8	PF 5510 03	Shaft Output	1	1	
9	PF 5512 06	2nd Driven Washer	1	1	
10	PF 5512 03	Gear 2nd Driven	1	1	
11	PF 5512 04	Gear 3rd Driven	1	1	
12	PF 5512 05	Gear 4th Driven	1	1	
13	JZ 5512 05	Bush 1st Driven	1	1	
14	JZ 5512 04	Gear 1st Driven	1	1	
15	JA 5510 08	Washer Thrust 1st Driven	1	1	
16	JA 5510 09	Collar Sprocket Drive	1	1	
17	59 2100 24	'O' Ring Collar Sprocket (13.8 X 1.9)	1	1	
18	JZ 5510 04	Sprocket Drive (Engine Sprocket)	1	1	
19	DU 1012 13	Plate Lock Sprocket	1	1	
20	39 1981 04	Socket Head Bolt	2	2	



 Front Wheel Direction


Transmission - UG 5 Gear

No.	Part No.	Description	Drum	Disc	Remarks
1	JZ 5510 10	Shaft Input W/o Gun Hole	1	1	
2	JE 5512 02	Gear 4th Drive K11	1	1	
3	39 0987 17	Ring Snap (17.2 X 20.5 X 1.5)	5	5	
4	JA 5510 02	Spline Washer (17.2 X 20.5 X 1.5)	3	3	
5	JE 5512 01	Gear 3rd Drive	1	1	
6	JE 5512 00	Gear 2nd Drive K11	1	1	
7	JA 5510 04	Washer Thrust 2nd Drive	1	1	
8	JZ 5510 08	Shaft Output Forging Route	1	1	
9	JE 5512 03	Gear 5th Drive K11	1	1	
10	JE 5512 05	Gear 2nd Driven K11	1	1	
11	JE 5512 06	Gear 3rd Driven K11	1	1	
12	JE 5512 16	Gear Fourth Driven	1	1	
13	JZ 5512 05	Bush 1st Driven	1	1	
14	JE 5512 15	Gear 1st Driven K11	1	1	
15	JA 5510 08	Washer Thrust 1st Driven	1	1	
16	JA 5510 09	Collar Sprocket Drive	1	1	
17	59 2100 24	'O' Ring Collar Sprocket (13.8 X 1.9)	1	1	
18	JZ 5510 04	Sprocket Drive (Engine Sprocket)	1	1	
19	DU 1012 13	Plate Lock Sprocket	1	1	
20	DS 1013 55	Bolt M5 Hex Socket Head	2	2	
21	JE 5512 08	Gear 5th Driven K11	1	1	
22	JZ 5512 10	Bush 2nd Driven	1	1	




Change Drum / Shift Fork

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 5610 00	Drum Assembly Comp	1	1	
	PF 5610 10	Drum Assembly Gear Shift	1	1	UG 5 Gear
2	39 0992 06	Dowel (Pin Drum Change)	5	5	
3	JA 5610 02	Cam Drum Change	1	1	
	JE 5610 05	Cam Drum Change K11	1	1	UG 5 Gear
4	JD 5610 11	Special Bolt Drum Change	1	1	
5	PF 5610 02	Shaft Fork Shift	2	2	
	JD 5610 06	Shaft Gear Fork Shift	2	2	UG 5 Gear
6	JD 5610 04	Fork Gear Shift Output	1	1	
7	JZ 5610 02	Fork Gear Shift Input	1	1	




Gear Change Mechanism

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 5612 00	Lever Gear Shift Comp	1	1	UG 5 Gear
	52 JZ02 64	Lever Comp Gear Shift	1	1	
2	JW 5612 06	Extension Spring	1	1	
3	JW 5612 08	Spring Gear Shift Return	1	1	
4	JA 5612 07	Inhibitor Complete Gear Shift	1	1	UG 5 Gear
	JH 5612 00	Inhibitor Gearshift C101	1	1	
	PA 5612 09	Inhibitor Comp D105A UG	1	1	
5	JA 5612 08	Spring (Inhibitor)	1	1	UG 5 Gear
	PF 5612 03	Spring Inhibitor B104d	1	1	
	JD 5612 04	Spring (Inhibitor)	1	1	
6	JA 5612 09	Step Washer (Collar)	1	1	
7	39 2704 11	Plain Washer	1	1	
8	39 0817 15	Hex Nut / Flange - M6	1	1	
9	JZ 5614 16	Gear Shift Lever	1	1	
10	DH 1015 09	Damper	1	1	
11	JH 5614 04	Rubber Damper Gsl	1	1	
12	LA D001 31	Bolt Flanged-m10x1.5x150xolv Grn	1	1	




Engine Assembly / Crankcase RH

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 5010 04	Assembly Engine	1	1	N.I 4 Gear
	PF 5011 08	Engine Assembly	1	1	UG 5 Gear
2	36 PF00 05	Kit Assembly C'case RH BM150	1	1	
	56 DY5E 3Q	Crankcase RH Silver(JH541007)	1	1	UG 5 Gear
3	KP BF62 03	Bearing Ball C3 Clearance-hn3	1	1	For I/P Shaft.
4	JA 5410 11	Needle Roller Bearing	1	1	For O/P Shaft.
5	JA 5410 10	Stopper Plate	1	1	
6	39 1000 06	Dowel Pin	2	2	
7	PF 5410 18	Bushing Drum BM-150	1	1	
8	DH 1013 80	Screw	1	1	
9	52 JA00 27	Stud Inhibitor Mounting	1	1	
10	39 1740 04	Bolt SH. :- 6 X 85	2	2	
11	59 0400 38	Bolt	1	1	
12	52 JA00 29	Bolt Shift Change	1	1	
13	JA 5410 12	Guide Kick	1	1	
14	39 1964 04	Flange Bolt - Small	2	2	
15	JH 5410 15	Gasket Crankcase	1	1	UG 5 Gear




Crankcase LH

No.	Part No.	Description	Drum	Disc	Remarks
1	36 PF00 04	Kit Assembly Crankcase LH	1	1	NRB + Bush
	PF 5411 09	Crankcase LH	1	1	UG 5 Gear
2	39 2562 20	Needle Roller Bearing	1	1	
3	KP BF62 03	Bearing Ball C3 Clearance-hn3	1	1	
4	39 1715 19	Seal Oil	1	1	Output Shaft
5	31 2010 81	Switch Complete	1	1	Neutral Switch
6	DH 1017 84	Gasket Neutral Switch (T.I.S)	1	1	
7	39 2190 19	Oil Seal	1	1	Shifter Shaft
8	JA 5410 05	Bush Bendix	1	1	
9	39 0747 01	Screw Pan Cross M6	2	2	
10	JA 5410 34	Stopper Gear Starter Aluminium	1	1	
	PF 6214 16	Stopper Gear Starter	1	1	UG 5 Gear
11	39 1000 06	Pin Dowel	4	4	
12	39 0999 06	Hollow Dowel Pin	4	4	
13	JG 5710 24	Mesh Oil Filter Assembly	1	1	
14	LJ A000 04	'O' Ring Strainer	1	1	
15	JV 5410 06	Cap Oil Filter	1	1	
16	59 0400 38	Bolt	6	6	
17	39 1759 04	Bolt (M6 X 1 X 55L)	1	1	C'case Mounting
18	59 2100 23	Ring 'O'	1	1	
19	JE 5410 38	Damper Crankshaft	1	1	




Cover RH

No.	Part No.	Description	Drum	Disc	Remarks
1	36 PF00 08	Kit Assembly Clutch Cover	1	1	Gauge + Circlip
	56 JV1V 3Q	Silver Cover Clutch (DY541201)	1	1	UG 5 Gear
2	PF 5412 17	Label Cover Boxer	1	1	
	JV 5412 25	Label Cover Clutch	1	1	UG 5 Gear
3	39 1041 19	Oil Seal Clutch Lever	1	1	
4	30 1011 42	Oil Seal (Kick Shaft)	1	1	
5	JV 5412 08	Shaft Clutch Release	1	1	
6	JE 5514 01	Rod Push	1	1	
	JE 5514 08	Rod Push K11	1	1	UG 5 Gear
7	DG 1014 18	Gauge	1	1	Oil Level Check
	JL 5412 27	Window Oil Gauge	1	1	UG 5 Gear
8	DS 1012 15	Wire Circlip	1	1	
9	39 2443 11	Washer - Plain	1	1	
10	JE 5412 14	Spring Torsion Clutch Lever	1	1	
11	JA 5412 11	Cap Oil Filler	1	1	
12	JA 5412 25	'O' Ring Cap Oil Filler	1	1	
13	JK 5412 12	Damper Clutch Cover PL BM-150	1	1	
14	JA 5412 16	Plate Damper	1	1	
15	DH 1013 88	Bolt Flange	3	3	
16	JA 5412 12	Gasket Clutch Cover	1	1	
17	59 0400 38	Bolt	8	8	
18	JV 5412 09	Bracket Clutch Cable	1	1	
	PF 5412 55	Bracket Clutch Cable	1	1	UG 5 Gear
19	DD 1211 81	Oil Filter Element	1	1	
20	39 1671 21	'O' Ring	1	1	
21	JV 5412 05	Cap Filter	1	1	
	JA 5412 19	Cap Filter	1	1	
	PF 5412 54	Cap Filter B104E	1	1	UG 5 Gear
22	39 1673 04	Bolt - Flange :- M6	3	3	
23	14 1510 33	Bearing- Ball	1	1	
24	39 0999 06	Pin Hollow Dowel	2	2	




Cover Magneto

No.	Part No.	Description	Drum	Disc	Remarks
1	36 PF00 07	Kit Assembly Cover Magneto	1	1	With Bush
	52 PF17 35	Cover Magneto	1	1	UG 5 Gear
2	39 1065 04	Bolt - Flanged :- Small	8	8	
3	JA 5412 05	Gasket Magneto Cover	1	1	
	PF 5412 86	Gasket Cover Magneto	1	1	UG 5 Gear
4	59 0400 38	Bolt	2	2	
5	JV 5412 12	Cover LH Rear Complete	1	1	
	PF 5412 87	Cover Assembly LH Rear	1	1	UG 5 Gear
6	JA 5410 05	Bush	1	1	Drive Gear Assly
7	JA 5412 33	Cap TDC Finder	1	1	
8	30 1011 95	'O' Ring	1	1	
9	DS 1611 50	Gear Shifter Label	1	1	
	JZ 5412 37	Label Gear Shift D125 2V	1	1	UG 5 Gear
10	JK 5412 14	Decal	1	1	
	PF 5412 17	Label Cover Boxer	1	1	
	PF 5412 49	Label Magneto Cover	1	1	UG 5 Gear




Clutch

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 5514 03	Clutch Assembly Complete	1	1	L.H. Threads
2	JD 5514 00	Spacer Clutch Assembly	1	1	
3	JA 5514 06	Collar Clutch	1	1	
4	39 2600 11	Washer	1	1	
5	36 PF00 09	Kit Plate Friction	1	1	
6	JA 5514 14	Wheel Clutch	1	1	
7	JA 5514 19	Plate Clutch (Steel Plate)	4	4	
8	JA 5514 15	Hub Clutch	1	1	
9	PF 5514 05	Compression Spring	4	4	
10	PF 5514 06	Holder Clutch	1	1	
11	39 1553 04	Bolt Flange M6	4	4	
12	39 2200 11	Belleville Washer	1	1	
13	39 0240 11	Plain Washer	1	1	
14	DH 1016 48	Nut Special Clutch Center Lock	1	1	
15	14 1510 33	Bearing - Ball	1	1	
16	36 JZ00 03	Set Primary Drive & Driven	1	1	




Kick Starter Mechanism

No.	Part No.	Description	Drum	Disc	Remarks
1	JA 6212 01	Lever Assembly Kick	1	1	
	PA 6212 03	Lever Assembly Kick	1	1	UG 5 Gear
2	JA 6212 06	Bolt Special	1	1	
3	36 DU10 07	Boss Kick Set	1	1	
	36 JH00 09	Kit Boss Kick Set	1	1	UG 5 Gear
4	22 1502 41	Plain Washer	1	1	
5	39 0993 11	Plain Washer Small	3	3	
6	39 0738 17	Circlip Shaft	2	2	
7	JA 6210 01	Shaft Kick	1	1	
	PA 6210 07	Shaft Kick D105A UG	1	1	UG 5 Gear
8	DS 1011 17	Spring Kick Starter Ratchet	1	1	
9	JA 6210 02	Ratchet	1	1	
10	JZ 6210 00	Assembly Kick Pinion Gear	1	1	
	PA 6210 08	Gear Kick Pinion D105A UG	1	1	UG 5 Gear
11	JA 6210 06	Washer Thrust (16.2 X 25 X 0.5)	1	1	
12	39 2408 17	Circlip	1	1	
13	DD 1010 97	Kick Rubber	1	1	
14	JE 5410 08	Spring Kick Starter Return	1	1	
	JE 6210 03	Spring K11	1	1	UG 5 Gear
15	JA 6212 06	Bolt Special (m8*30)	1	1	N.I
16	JE 6210 04	Sleeve K11	1	1	UG 5 Gear




Carburettor

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 5812 00	Carburettor Assembly	1	1	UG 5 Gear
	PF 5812 68	Carburettor	1	1	
2	JA 5812 23	Mixing Cap Assembly	1	1	
3	DH 1211 69	Pilot Screw Kit	1	1	
4	36 PF00 21	Kit Jet BM 150	1	1	N.I.
5	36 JZ00 16	Idling Screw Kit	1	1	
6	JA 5812 21	Needle Valve Assembly	1	1	
7	24 1213 65	Float Complete	1	1	
8	CB 1210 42	Screw Washers Bowl M4x14	4	4	
9	39 1062 04	Screw TPS	1	1	
10	JB 5812 02	Throttle Position Sensor	1	1	
11	JB 5812 04	"O" Ring (TPS)	1	1	
12	36 PF00 22	Kit Piston Valve BM 150	1	1	
13	36 PF00 24	Kit Carburetor Gasket/O Ring	1	1	
14	24 1210 69	Arm Pin Float	1	1	
15	JA 5813 14	Drain Screw	1	1	
16	JZ 5812 20	Hose Drain	1	1	
17	JZ 5812 16	Spring	1	1	
18	JA 5812 91	Cable Adjuster	1	1	
19	36 PF00 23	Kit Choke Plunger BM 150	1	1	
20	30 1210 04	Ring - Snap	1	1	




Air Cleaner Complete

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 5810 03	Air Filter Assembly	1	1	Intake
2	PF 5810 02	Duct Air Intake	1	1	
3	DF 1614 26	Bolt - Stepped with Flange	2	2	
4	PF 5810 12	Element Air Filter	1	1	
5	JA 5810 09	Flame Arrester	1	1	
6	JA 5810 12	Tube Drain	1	1	
7	DS 1211 26	Plug	1	1	
8	DP 1210 25	Clamp	1	1	
9	JA 5110 11	Hose Breather	1	1	
10	JB 5810 01	Air Intake Duct	1	1	
11	PF 5810 19	Cartridge Cover Assembly	1	1	
12	JA 5810 11	'O' Ring Cartridge Cover	1	1	
13	39 1773 04	Flange Bolt	4	4	
14	DH 1210 38	Clamp	1	1	N.I Ref.Cir.IB-418
15	39 1779 02	Self Tapping Screw	2	2	
16	39 1677 04	Hex Head Screw	2	2	
17	JE 5910 02	Gasket Exhaust	1	1	
	JE 5912 80	Gasket Exhaust	1	1	
18	AA 1210 45	Clamp (Duct Carburettor)	1	1	




Silencer Assembly

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 5910 17	Silencer Assembly	1	1	CAT, Wire Shield
	PF 5910 59	Assembly Silencer	1	1	W/O CAT, W/O Wire Shield
2	CB 1011 14	Gasket Exhaust Mounting	1	1	
3	39 2295 15	Flange Nut	2	2	
4	39 2754 04	Bolt Hex with Flange M5	1	1	
5	39 2492 11	Plain Washer	1	1	
6	39 2722 04	Bolt M10 x 1.25	1	1	
7	JB 1130 05	Washer	2	2	
8	PF 5910 45	Shield Muffler	1	1	
9	DH 1016 07	Truss Screw	4	4	
10	PF 5910 43	Wire Shield	1	1	




Oil Pump

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 5710 00	Oil Pump Assembly	1	1	
2	JA 5410 16	Gasket Case Oil Pump	1	1	
3	FD 1010 78	Pan Head Screw M6 X 1 X 3DL	3	3	
4	39 0999 06	Dowel	2	2	
5	PF 5710 01	Gear Oil Pump	1	1	




Starter Assembly

No.	Part No.	Description	Drum	Disc	Remarks
1	JA 6214 14	Body Complete Starter Clutch	1	1	
	GL 6214 14	One Way Clutch_10 Roller_D103	1	1	UG 5 Gear
2	DH 1017 81	Plate Roller Clutch	1	1	
3	JZ 6214 05	Gear Starter	1	1	
	JH 6214 03	Gear Starter Clutch Assembly	1	1	UG 5 Gear
4	39 2200 11	Washer - Plain (Primary Drive Gear)	2	2	
5	JA 6214 06	Drive Assembly	1	1	
5a	JH 6214 07	Gear Drive Starter Clutch	1	1	UG 5 Gear
6	36 JZ00 08	Starter Clutch Repair Kit	1	1	
7	PF 3516 00	Starter Motor	1	1	
	JH 3516 03	Motor Starter	1	1	UG 5 Gear
8	DH 1013 80	Screw - Pan - Precoated	3	3	
9	JA 3516 06	Sealing Ring (Flash)	1	1	
	JA 3516 26	Sealing Ring (Lucas-TVS)	1	1	
10	LA D000 11	Flange Bolt M6x20	2	2	Motor Mounting
11	JA 3516 02	'O' Ring For Spigot (Flash)	1	1	
	JA 3516 27	'O' Ring For Spigot (Lucas-TVS)	1	1	
12	JA 3516 08	+ve Brush Holder Assembly (Flash)	1	1	
13	JA 3516 09	-ve Brush Holder Assembly (Flash)	1	1	
14	JA 3516 18	Brush & Earth Plate Assembly	1	1	N.I (Lucas-TVS)
15	JA 3516 24	Brush Spring (Lucas-TVS)	1	1	N.I.
16	JA 3516 19	Terminal Assembly (Lucas-TVS)	1	1	
17	39 0849 14	Washer Lock - Toothed	3	3	




Magneto, CDI & H.T. Coil

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 3510 03	Assembly Rotor	1	1	
	PA 3510 27	Rotor Assembly	1	1	UG 5 Gear
2	PF 3510 04	Stator Assembly	1	1	
	PF 3510 69	Stator Assembly	1	1	UG 5 Gear
3	39 1674 04	Bolt Flange M6 X 28	2	2	
4	DH 1013 80	Pan Head Screw M6 X 12	3	3	
5	JV 3512 04	H. T. Coil With Cable	1	1	
6	PF 3512 01	CDI Assembly Sealed Coupler	1	1	
	PF 3512 42	CDI	1	1	UG 5 Gear
7	DD 1110 18	Plug - Spark (for Champion P-rz9hc)	1	1	
	CF 1110 19	Spark Plug UR4AC	1	1	UG 5 Gear
8	DD 1110 48	Spark Plug Cap	1	1	
9	DD 1110 11	Grommet Spark Plug Cap	1	1	
10	JG 3510 16	Grommet "H"	1	1	
11	39 1943 04	Bolt Flange M6	2	2	
12	JN 4020 00	RR Unit With Capacitor	1	1	
	JW 4020 01	DC Regulator With Capacitor	1	1	UG 5 Gear
13	JA 5410 28	Lock Plate	1	1	
14	59 0400 14	Bolt Flange (N.I.)	4	4	HT Coil Mounting




Seat Assembly

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 1910 00	Seat Assembly Complete	1	1	Ref.Cir.IB-388
	JV 1910 01	Seat Assembly Complete	1	1	
2	FD 2110 06	Grommet Seat	2	2	
3	FD 2110 07	Spacer Seat	2	2	
4	39 1211 11	Washer Plain	2	2	
5	LA C000 21	Bolt Hexagon Socket Head	2	2	
6	PF 2314 05	Grip Frame	1	1	
	PF 2314 17	Frame Grip	1	1	
7	39 1556 04	Bolt Flange	2	2	
8	DP 2110 09	Damper For Seat	7	7	
9	JV 1910 03	Seat Foam (Density 78)	1	1	




Engine Mountings

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 1134 02	Bracket Engine Hanger	2	2	
2	JA 1134 02	Engine Mounting Bracket Front	1	1	
3	39 2723 15	Hex Nut Flanged	2	2	Engine Mtg. Rear
4	JA 1134 03	Bolt Flanged	2	2	Engine Mtg. Rear
5	39 2312 04	Bolt Flanged	3	3	Engine Mtg. Top
6	39 1970 15	Nut Flanged	7	7	Engine mtg.Top&FR
7	59 0400 17	Hex Bolt Flanged	4	4	Engine Mtg. Front
8	KA DD08 85	Bolt Flanged	–	1	N.I




Frame and Frame Fittings

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 1110 00	Frame Assembly	1	1	N.I.
2	DS 1810 18	Nut with Dust Cap	1	1	
3	36 DZ20 08	Kit St. Cone With Grease	1	1	
4	DJ 1811 15	Cage Bearing	2	2	
5	DH 1810 14	Cup Steering	1	1	
6	39 0720 09	Rivet - Round	1	1	



Swing Arm / Rear Shock Absorber


No.	Part No.	Description	Drum	Disc	Remarks
1	JB 1220 16	Hex Bolt / Flange - M10	2	2	
2	39 0714 11	Plain Washer	2	2	
3	39 2349 11	Plain Washer	4	4	
4	PF 1220 04	Shock Absorber Rear	2	2	
	PF 1220 33	Rear Shock Absorber	2	2	UG 5 Gear
	PF 1220 50	Shock Absorber Rear	2	2	Ref.Cir.IB-451
	PF 1220 56	Shock Absorber Rear	2	2	Ref.Cir.IB-451
5	52 PF02 19	Ckd Set Of Swing Arm Assembly	1	1	With Bush
	PF 1220 30	Arm Assembly Swing	1	1	
	52 JV01 06	Swing Arm Assembly	1	1	UG 5 Gear
6	DP 1710 06	Bushing Rubber	2	2	
7	39 2366 15	Domed Cap Nut	2	2	
8	39 0789 12	Spring Washer	2	2	
9	JB 1220 03	Chain Slider	1	1	
10	39 0553 02	Screw - Self Tapping	2	2	For Chain Sider
11	39 0454 11	Washer - Plain	2	2	For Chain Sider
12	JA 1210 03	Shaft Swing Arm	1	1	
13	39 0939 15	Nylock Nut	1	1	
14	DJ 1510 36	Adjuster Chain LH	1	1	
15	DJ 1510 37	Adjuster Chain RH	1	1	
16	39 0292 15	Hexagon Nut	4	4	
17	DJ 1510 47	Plate Chain Adjuster	2	2	
18	KB RC35 13	Screw Tapping Pan Cros	2	2	
19	DH 1510 29	Bolt - Step Torque Rod	1	1	
20	KD DB10 18	Washer Spring Thin	1	1	
21	KH BA08 28	Pin Snap	1	1	



Front Wheel Direction


Rider Foot Rest / Pillion Foot Rest

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 1130 00	Main Step LH	1	1	
2	KA DF08 22	Bolt Flanged	4	4	
3	PF 1130 01	Main Step RH	1	1	
4	DF 1614 13	Damper - Step :- Front In 'PVC'	2	2	
	PF 1130 28	Damper Rider Footrest	2	2	UG 5 Gear
5	DH 1611 94	Kick Stopper	1	1	For Kick stopper
6	PF 1130 02	Stay LH	1	1	
	PF 1130 58	Holder Step Pillion LH	1	1	UG 5 Gear
7	PF 1130 03	Stay RH	1	1	
	PF 1130 59	Holder Step Pillion RH	1	1	UG 5 Gear
8	DP 1611 70	Step Pillion Footrest LH/RH	2	2	
9	KA DD08 22	Bolt-flange-kad St-d Dia-08 L-22	2	2	N.I
10	39 2481 04	Bolt Hex With Flange M8	4	4	
11	39 2659 12	Washer - Spring	4	4	
12	DG 1612 24	Damper	1	1	
13	PF 1130 60	Step Pillion LH	2	2	UG 5 Gear
14	PF 1130 61	Step Pillion RH	2	2	UG 5 Gear
15	JK 1130 08	Rubber Pillion Step	2	2	
16	30 1710 22	Pin	2	2	
17	DP 1611 63	Washer For Rear Foot Step	2	2	
18	39 0784 08	Pin - Split	2	2	




Mudguard - Front & Rear

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 1814 30	Front Fender Front	1	1	
2	30 2110 05	Collar	3	3	
3	DD 2010 11	Damper	3	3	
4	KA DF06 25	Bolt Flange	1	1	
5	PF 1814 31	Bkt Mtg Front Fender Front	1	1	
6	KA DT06 12	Bolt Flanged-m6x1x12xcl8.8xblak	2	2	
7	DJ 1810 65	Clip nut	2	2	
8	PF 1814 32	Front Fender Rear	1	1	
	PF 1814 47	Fender Front Rear	1	1	Ref.Cir.IB-451
9	DJ 1610 69	Nail Cable Guide	1	1	
10	DS 1611 25	Cable Guide	1	1	
11	PF 1814 33	Brace Front Fender Rear	1	1	
	PF 1814 48	Brace Fender Front Rear	1	1	Ref.Cir.IB-451
12	KA DF08 20	Bolt Flanged	3	3	
13	KA DF06 30	Bolt	2	2	
14	DD 1614 37	Rivet - Special :- Black	4	4	N.I
15	JV 1814 08	Fender- Rear (combined)	1	1	
16	JV 1814 10	Flap Fender Rear	1	1	
17	39 1943 04	Bolt - Flanged	3	3	
18	39 0211 11	Washer - Plain	3	3	




Stand Assembly

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 1132 02	Stand Center	1	1	
	PF 1132 24	Stand Center	1	1	UG 5 Gear
	PF 1132 25	Stand Center	1	1	Ref.Cir.IB-451
2	JA 1132 01	Shaft Stand	1	1	
	39 0797 08	Pin - Cotter	1	1	
	KH AA32 30	Pin Cotter	1	1	UG 5 Gear
3	KH AA32 25	Pin Cotter	1	1	Ref.Cir.IB-451
	DH 1611 21	Spring Stand Center	1	1	
	JZ 1132 05	Spring Tension	1	1	Ref.Cir.IB-451
4	JA 1132 02	Stand Side	1	1	
	PF 1132 26	Stand Side	1	1	Ref.Cir.IB-451
	DH 1610 66	Spring Side Stand	1	1	
5	DF 1611 02	Bolt	1	1	
	39 0422 15	Nut Nyloc M10	1	1	
	DG 1611 24	Damper Main Stand	1	1	




Tube / Tyre / Rim

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 1310 33	Wheel Front 1.6x17-5 Spoke 130 Blk	1	-	
	DJ 1510 77	Wheel 1.6 X 17 - Dc Black	-	1	
2	PF 1310 08	Tyre Front 3 X 17 RIM with Tube	1	1	
3	JZ 1312 06	Wheel Rear 2.15x17 Drum	1	-	
	DH 1510 57	Wheel 2.50x17	-	1	
4	PF 1312 15	Tyre Rear 100 x 90, 17, 55P with Tube	1	1	




Front Hub - For Drum Brake

No.	Part No.	Description	Drum	Disc	Remarks
1	JB 1310 17	Axle Front	1	—	UG 5 Gear
	DJ 1510 41	Axle	1	—	
2	JB 1310 18	Plain Washer	1	—	
3	DS 1510 56	Dust Seal	1	—	(N.I.)
4	DS 1510 60	Spacer Assembly	1	—	
5	KP BB62 02	Bearing Ball	1	—	UG 5 Gear
6	30 1510 33	Oil Seal	1	—	
7	30 1510 32	Collar Bearing	1	—	
	30 1510 75	Collar - Bearing	1	—	
8	KP BB63 01	Bearing Ball C3 Clearance	1	—	UG 5 Gear
9	JN 1318 12	Brake Shoe Kit(Non Asbestos)	1	—	
10	30 1510 69	Spring	2	—	
11	59 1500 03	U Nut	1	—	
12	DS 1510 89	Cam Brake Assembly	1	—	
13	30 1510 38	Ring 'O'	1	—	
14	DS 1510 91	Wear Indicator	1	—	
15	KA EF06 30	Bolt	1	—	
16	DS 1510 92	Lever Brake	1	—	
17	DS 1510 94	Nut	1	—	
18	KB BA04 08	Screw Pan Cross	1	—	Secure Speedo Cable
19	39 0732 12	Washer Spring	1	—	
20	30 1511 18	Stopper for Bushing	1	—	
21	LD B000 01	Screw	1	—	N.I
22	36 DS15 02	Speedometer Gear Kit	1	—	
23	30 1510 35	Seal Oil	1	—	
24	39 0242 11	Washer Plain	2	—	
25	39 1013 21	'O' Ring	1	—	
26	JA 1316 06	Bushing Speedo Gear	1	—	
27	PF 1318 11	Panel Assembly Fr	1	—	




Front Hub - For Disc Brake

No.	Part No.	Description	Drum	Disc	Remarks
1	DJ 1510 41	Axle	-	1	
2	DE 1510 08	Seal - Oil	-	1	
3	DE 1510 12	Plate - Drive For Speedometer Gear	-	1	
4	KP BB63 01	Bearing Ball-C3 Clearance	-	2	
5	DE 1510 06	Spacer Assembly	-	1	
6	30 1510 33	Seal - Oil	-	1	
7	JN 1318 07	Brake Disc	-	1	
8	DH 1016 47	Bolt M6 Hex. Socket Head	-	6	
9	KD AA12 22	Washer Plain Small	-	1	
10	DH 1710 19	Nut - U :- Swing Arm	-	1	
11	DS 1510 56	Dust Seal	-	1	
12	PF 1316 12	Case Assembly - Meter Gear	-	1	
13	DE 1510 11	Gear - Speedometer	-	1	
14	KD DB04 08	Washer Spring Thin	-	1	
15	KB BA04 08	Screw Pan Cross	-	1	
16	30 1511 18	Stopper For Bushing	-	1	
17	39 1013 21	Ring - O	-	1	
18	39 0242 11	Washer - Plain	-	2	
19	30 1510 41	Gear Meter Screw	-	1	
20	JA 1316 06	Bushing	-	1	




Front Master Cylinder

No.	Part No.	Description	Drum	Disc	Remarks
1	DE 1910 43	Major Kit - Master Cylinder	—	1	Ref.Cir.IB-451
2	JN 1318 00	Hose Assembly	—	1	
	PF 1318 35	Hose Assembly	—	1	
3	DJ 1910 57	Lever Grip RH	—	1	Ref.Cir.IB-451
4	DJ 1910 25	Banjo Bolt	—	2	
	GL 1318 27	Bolt Banjo	—	2	
5	DJ 1910 26	Washer Copper	—	4	
6	DE 1910 33	Clamp Holder RH	—	1	
7	DJ 1910 28	Bolt	—	2	
8	DJ 1910 29	Bolt Front Brake Lever	—	1	
9	DJ 1910 30	Nut Flanged	—	1	
10	DE 1910 30	Screw	—	2	
11	DJ 1910 56	Cylinder Master	—	1	
12	DJ 2011 09	Front Brake Switch	—	1	
13	DE 1910 29	Reservoir Cover	—	1	
14	DE 1910 28	Diaphragm	—	1	
15	JL 5412 27	Window Oil Guage	—	1	




Front Disc Brake - Caliper

No.	Part No.	Description	Drum	Disc	Remarks
1	DG 1510 89	Caliper Assembly Front	—	1	Ref.Cir.IB-451
	PD 1318 53	Caliper Assembly Front	—	1	
2	DE 1510 45	Dust cover	—	1	
3	DE 1510 48	Spring Pad	—	1	
4	36 PD00 43	Kit Caliper Assembly Pad Spring	—	1	
5	DE 1510 46	Bleeder Screw	—	1	
6	DE 1510 47	Bleeder Cap	—	1	
7	JW 1318 07	Brake Pad Set	—	1	
8	DE 1510 43	Insulator	—	1	
9	36 DJ40 32	Minor Kit - Caliper	—	1	
10	36 DJ40 33	Major Kit - Caliper	—	1	



Rear Hub


No.	Part No.	Description	Drum	Disc	Remarks
1	DJ 1510 53	Drive Chain Lock	1	1	
2	36 PF00 10	Chain Sprocket Kit	1	1	
3	39 0801 15	Nut	2	2	
4	39 2567 11	Plain Washer	2	2	
5	DJ 1510 35	Collar	1	1	
6	KP BC60 04	Bearing Ball	1	1	
7	DS 1510 68	Coupling	1	1	
8	DS 1510 73	'D' Bolt	4	4	
9	LC B000 05	Hex Lock Nut	4	4	
10	PF 1312 20	Washer	2	2	
11	DJ 1510 33	Sleeve	1	1	
12	KP BC62 02	Bearing Ball	1	1	
13	30 1510 75	Collar Bearing	1	1	
14	DK 1510 94	Coupling Rubber	1	1	
15	KP BC63 02	Bearing Ball	1	1	
16	30 1510 69	Spring	2	2	
17	JN 1318 12	Shoe Brake Kit	1	1	
18	DJ 1510 92	Panel Rear Brake	1	—	
	DS 1510 69	Panel Brake Rear	—	1	
19	DS 1510 89	Cam Brake Assembly	1	—	
	30 1510 11	Cam Brake Assembly	—	1	
19A	39 0722 11	Plain Washer	1	1	
20	30 1510 38	Ring 'O'	1	1	
21	DS 1510 90	Indicator	1	1	
22	JW 1316 01	Lever Brake	1	1	
23	KA EF06 30	Bolt	1	1	
24	PF 1312 08	Axle - Rear (dia.15)	1	1	
25	DX 1510 22	Collar	1	1	
26	DS 1510 94	Nut M6	1	1	
27	DH 1710 19	Nut U Swing Arm	1	1	
28	39 1075 04	Bolt - Flanged :- Small	1	1	
29	DS 1510 57	Dust Cover Rear	—	1	
30	39 2566 11	Washer - Plain	1	1	
31	DS 1510 69	Panel Brake Rear - 4 Rubber	1	1	



FWD Front Wheel Direction


Rear Brake Pedal

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 1610 02	Brake Pedal	1	1	
2	PF 1610 01	Rod Brake	1	1	
3	30 1910 38	Pin	1	1	
4	DS 1910 35	Packing Brake rod	1	1	
5	39 0198 11	Plain washer	2	2	
6	39 0808 08	Split pin	1	1	
7	39 0805 11	Plain Washer	1	1	
8	39 0797 08	Pin Cotter	1	1	
9	JV 1610 14	Brake Pedal Return Spring	1	1	
10	39 0198 11	Washer Plain	2	2	
11	30 1910 35	Spring	1	1	
12	JB 1610 02	Pin Brake Rod	1	1	
13	30 1910 36	Nut Brake Adjuster	1	1	
14	JW 1220 04	Rod Torque	1	1	
15	DH 1510 29	Step Bolt Torque Rod	1	1	
16	39 1540 11	Plain Washer	1	1	
17	39 0789 12	Spring Washer	2	2	
18	39 0694 15	Hex. Lock Nut M8 x 1.25	1	1	
19	39 0807 08	Split Pin	2	2	
20	30 1510 95	Bolt Hex.	1	1	
21	39 0708 15	Nut Hex. M10 X 1	1	1	
22	DD 1610 78	Damper	1	1	
23	JD 4022 17	Band(L 150)	2	2	N.I




Handle Bar

No.	Part No.	Description	Drum	Disc	Remarks
1	DU 1810 21	Handle Bar	1	1	
2	PF 2326 01	Lock Kit (3 IN 1)	1	1	
	PF 2326 05	Lock Kit	1	1	UG 5 Gear
2a	DS 1810 22	Switch Assembly - Ignition	1	1	N.I.
3	DJ 2210 03	Mirror Assembly LH	1	1	
4	DJ 2210 04	Mirror Assembly RH	1	1	
5	DJ 1910 83	Lever Control LH	1	1	
6	DJ 1910 81	Holder LH	1	1	
7	DS 1910 52	Boot For Lever LH	1	1	
8	DU 1910 09	Grip LH	1	1	
9	JB 4014 00	Control Switch LH	1	1	
10	JZ 4014 05	Clutch Switch	1	1	N.I.
11	36 DU19 01	Kit Cable Adjuster	2	2	N.S
12	39 1553 04	Flanged Bolt	4	4	
13	36 DS18 01	Holder Handle Set	2	2	
14	DS 1910 52	Boot For Lever RH	1	1	
15	DD 1911 42	Lever RH	1	—	
16	PF 4014 17	Switch Control RH	1	—	
	JZ 4014 08	Switch Control RH	—	1	
17	DU 1910 03	Hand Grip Assembly RH	1	1	
	PF 1510 32	Grip Assembly RH	1	1	Ref.Cir.IB-398
18	DS 1810 07	Washer Handle Upper	2	2	
19	DS 1810 08	Damper Handle Upper	2	2	
20	DS 1910 38	Holder Assembly - RH	1	1	




Handle Bar

No.	Part No.	Description	Drum	Disc	Remarks
21	36 DK00 37	Kit Mirror Holder	2	2	Ignition Switch
22	DD 2011 70	Front Brake Switch	1	1	
23	39 0422 15	Nut Nyloc M10	2	2	
24	30 1910 48	Band	2	2	
25	39 1943 04	Flange Bolt	2	2	
26	JZ 1610 25	Assembly Lever-Holder LH	1	1	




Front Fork

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 1210 80	Fork Front	1	–	Silver Fork
	PF 1211 18	Fork Front	1	–	Black Fork
	PF 1211 24	Fork Front	1	–	Ref.Cir.IB-451
	PF 1211 19	Fork Front	–	1	
	PF 1211 44	Fork Front	–	1	Ref.Cir.IB-451
2	36 DK00 20	Front Fork Seal Kit	2	2	
2A	DJ 1810 87	Seal Oil	2	2	
3	30 1810 26	Gasket	2	2	
4	39 1813 04	Bolt	2	2	
5	PF 1210 17	Fork Pipe Inner	2	2	
6	DS 1810 84	Spring Front Fork	2	2	
7	59 0400 06	Bolt Fork	2	2	With Washer
8	DS 1810 15	Cap Nut Fork	1	1	
9	DS 1810 16	Plain Washer	1	1	For Cap Nut
10	DS 1810 05	Bracket Upper Front Fork	1	1	
11	DH 1810 25	Bearing Cone	1	1	
12	PF 1210 85	Holder Assly Front Fork Comp	1	1	
13	39 0789 12	Spring Washer	2	2	
14	39 1813 04	Bolt	2	2	
15	PF 1210 18	Pipe Left Fork Outer	1	–	
	PF 1210 37	Pipe Outer - LH	–	1	
16	PF 1210 19	Pipe Right Fork Outer	1	–	
	PF 1210 39	Pipe Outer - RH	–	1	
17	DS 1810 06	Holder - Handle	2	2	
18	31 1810 99	Spring - Front Fork	2	2	
19	DS 1810 12	Bolt Fork	2	2	
20	30 1810 29	'O' Ring	2	2	
21	PF 1210 24	Lamp Shade Assly.	1	1	
22	DJ 1810 51	Cover Trail A	2	2	
23	PF 1210 28	Damper Cover Fork	2	2	
24	DJ 1810 52	Cover Trail B	2	2	
25	DJ 1810 85	Cushion Rubber	2	2	
26	DS 1810 70	Bush Guide	2	2	
27	DS 1810 72	Washer Guide Bush	2	2	




Front Fork

No.	Part No.	Description	Drum	Disc	Remarks
28	PF 1210 83	Bellow Front Fork	2	2	
29	PF 1210 54	Clamp For Bellow	2	2	
30	KA DD06 14	Bolt-Flange-kad	2	2	N.I
31	PF 1211 16	Leg Assembly LH	1	–	N.I
	PF 1211 20	Leg Assembly LH	–	1	N.I
32	PF 1211 17	Leg Assembly RH	1	–	
	PF 1211 21	Leg Assembly RH	–	1	




Fuel Tank, Cap Tank and Gauge Fuel

No.	Part No.	Description	Drum	Disc	Remarks
1	DS 1410 09	Cap Assembly Tank	1	1	
2	39 0761 01	Screw Pan Cross	2	2	
3	39 2179 24	Washer	2	2	
3A	30 1410 31	'O' Ring	2	2	
4	PF 1718 00	Fuel Tap	1	1	
5	PF 2326 05	Lock Kit	1	1	
6	PF 4026 00	Sensor Fuel Level	1	1	With 'O' Ring
7	JH 1710 17	O Ring Fuel Gauge	1	1	
8	39 2484 15	Flanged Nut	4	4	
9	PF 1718 03	Pipe Fuel	1	1	Cock to Carburetor
10	DK 1410 41	Pipe Clip	2	2	




Fittings - Fuel Tank, Side Covers & Cover Seat

No.	Part No.	Description	Drum	Disc	Remarks
1	36 DS14 01	Grommet Kit for Side Cover	1	1	For Tank
2	DG 1611 21	Screw	1	1	
3	DU 1611 02	Damper	1	1	
4	JV 1710 01	Damper Tank Rear	1	1	
5	39 1789 24	Washer Nylon	3	3	
6	39 0983 08	Pin Snap	1	1	For Tank Mounting
7	39 1054 11	Plain Washer	1	1	
8	DJ 1410 08	Damper Front	2	2	




Meter Assembly

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 4024 00	Meter Assembly	1	1	UG 5 Gear
	PF 4024 16	Speedometer	1	1	
2	PF 4024 01	Speedometer Machine With Dial	1	1	
3	PF 4024 05	Fuel Gauge Machine with dial	1	1	
4	PF 4024 02	Speedo meter Top Cover	1	1	
5	PF 4024 06	Speedo meter Bottom Cover	1	1	
6	PF 4024 03	Speedometer wiring harness	1	1	
7	CL 2010 42	Bulb 12V - 2 W	4	4	
8	DH 1910 37	Bulb 12V - 3 W	3	3	
9	PF 4024 04	Speedometer Bracket	1	1	
10	39 0798 15	Flanged Nut	2	2	
11	DE 1510 11	Gear - Speedometer	-	1	
12	30 1510 41	Gear Meter Screw	1	1	




Control Cables

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 1612 17	Cable Throttle	1	1	Ref.Cir.IB-398
	PF 1612 37	Cable Throttle	1	1	
2	PF 1612 12	Cable Clutch	1	1	
3	JZ 1612 10	Cable Speedometer	1	1	Ref.Cir.IB-451
	DZ 1910 14	Cable - Speedometer W/o Bent Tube	1	1	
4	PF 1612 09	Cable Speedometer Inner	1	1	
5	PF 1612 13	Cable front Brake	1	–	Ref.Cir.IB-451
	PF 1612 45	Cable Brake	1	–	
	DJ 2011 08	Cable Assembly Front Brake Microswitch	–	1	
6	39 1561 21	'O' Ring	1	1	N.I.



Chain Case


No.	Part No.	Description	Drum	Disc	Remarks
1	36 PF00 11	Kit Chain Case	1	1	
2	15 1610 69	Rubber Cap	1	1	
3	DH 1612 83	Bolt Chain Case	2	2	
4	JB 1812 20	Flange Bolt M6 X 1P X 62 L	2	2	



Front Wheel Direction


Head Lamp & Fairing

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 4010 00	Head Light Assembly/ Lmp	1	–	
	PF 4010 16	Head Light Assembly	–	1	
2	DL 1810 10	Nut-well M5	4	4	
3	39 2141 24	Washer (Non Metallic Washer)	4	4	
4	DU 2010 29	Special Screw	2	2	
5	DS 2010 19	Collar	2	2	
6	DS 2010 20	Damper I	2	2	
7	DS 2010 21	Damper II	2	2	
8	39 2582 04	Flange Bolt M-8 L 35	2	2	
9	39 1970 15	Flange Nut M-8	2	2	
10	CL 2010 23	Lamp 12 V 35/35 W HS1	1	1	
11	PF 4010 09	Lamp Holder (Socket) Assembly	1	1	
12	PF 1210 25	Fairing Structure	1	1	
13	JW 1812 32	Bolt Flange M6	4	4	
14	JW 1812 29	Plain Washer	6	6	
15	JB 1510 12	Grommet Fairing Mounting	4	4	
16	JB 1510 13	Sleeve Fairing Mounting	4	4	
17	39 0798 15	Hex Nut	2	2	
18	35 1610 60	Nut - Clip	4	4	
19	39 1765 11	Washer - Plain	4	4	
20	39 2238 01	Screw - Pan Head	4	4	
21	PF 1812 11	Grommet - Cowling Mtg	2	2	N.I.
22	PF 1812 09	Windshield	1	1	
23	DL 1810 09	Screw - M5 X L 16	4	4	
24	DJ 2010 51	Reflector with Lens	1	1	




Indicator Light Assembly

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 4010 01	Dir. ind. Front LH with Lamp	1	1	UG 5 Gear
2	PF 4010 02	Dir. ind. Front RH with Lamp	1	1	
3	PF 4010 03	Dir. ind. Rear LH with Lamp	1	1	
4	PF 4010 04	Dir. ind. Rear RH with Lamp	1	1	
5	18 2010 44	Lamp :- 12V - 10W - R 10W	4	4	
	20 2010 29	Lamp :- 12V - 21/5W, P 21/5W	4	4	
6	DU 2010 16	Lens	4	4	
7	39 1225 15	Hex. Nut	4	4	



Tail Lamp Assembly / Front Number Plate


No.	Part No.	Description	Drum	Disc	Remarks
1	PF 4010 05	Tail Light Assembly	1	1	
2	CL 2010 23	Lamp 12 V, 10/5W	1	1	
3	39 2430 15	Hex Nut. / Flange	2	2	
4	DD 2010 11	Damper	2	2	
5	31 2010 01	Collar	2	2	
6	39 2429 11	Plain Washer	2	2	
7	PF 2314 01	Bracket Tail Light Assembly	1	1	
8	39 1956 04	Bolt Flange Small (for No. Plate)	2	2	
9	DF 1612 52	Plate No. Rear Black	1	1	
10	39 2765 01	Screw Truss M6	2	2	
11	DM 2010 26	BOOT	1	1	
	PF 4022 10	Boot	1	1	UG 5 Gear
12	30 2010 69	Reflector Reflex	1	1	N.I.
13	39 1972 15	Nut Hexagon with Flange M5	1	1	N.I Reflector Mtg.
14	KC MB06 05	Nut Weld Square	2	2	
15	DP 1611 01	Bracket Assembly Mtg Number Plate	1	1	



 Front Wheel Direction


Electrical Equipments

No.	Part No.	Description	Drum	Disc	Remarks
1	JV 4016 02	DC Horn	1	1	
2	39 1689 04	Flange Bolt (M8)	1	1	
3	PF 4022 13	Harness Wiring	1	1	
	PF 4022 54	Harness Wiring	1	–	UG 5 Gear
	PF 4022 61	Harness Wiring	–	1	UG 5 Gear
	PF 4022 62	Harness Wiring	1	1	
4	PF 4014 04	Rear Brake Switch	1	1	
5	PF 4014 03	Spring Brake Switch	1	1	
6	DS 2010 82	Battery Mf Dry Charged 5AH	1	1	
	JF 4018 07	Battery Dry Vrla 4AH	1	1	UG 5 Gear
7	JV 4018 01	Case Battery	1	1	
8	JA 4018 01	Band Battery	1	1	
9	DS 2010 25	Assembly DC Flasher	1	1	
10	JK 3516 00	Starter Relay	1	1	With Grommet
11	30 2011 04	Fuse Box Assembly	2	2	Light Main Fuse
12	GF 2010 53	Fuse (10 Amp.)	2	2	Light & Main Fuse
	AK 2010 12	Fuse - 10a (Blade Type)	3	3	
	AP 2010 25	Fuse 15a (Blade Type)	2	2	
13	JV 4022 04	Starter Relay to Motor Relay	1	1	
	PA 4022 48	Cable Relay To Motor	1	1	UG 5 Gear
14	JV 4022 05	Cable Assy Battery To Earth	1	1	
	PA 4022 56	Cable Assembly Battery To Earth	1	1	UG 5 Gear
15	LA D001 31	Bolt Flanged-m10x1.5x150xlv Grn	1	1	
16	KA DD06 10	Bolt Flanged	1	1	
17	CS 2010 26	Terminal For Battery Positive	1	1	
	PF 4022 22	Terminal Battery Z Shape	1	1	UG 5 Gear
18	PF 3518 00	Sensor Indicator Gear	1	1	UG 5 Gear
19	PF 4034 00	Socket Charger	1	1	UG 5 Gear
20	JF 4018 08	Bottle Acid 4AH	1	1	UG 5 Gear



Tool Kit

No.	Part No.	Description	Drum	Disc	Remarks
1	DM 2210 13	Tool Kit	1	1	



Accessories

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 1130 08	Footrest Third LH	1	1	UG 5 Gear
	PF 1130 60	Step Pillion LH	1	1	
2	PF 1130 09	Footrest Third RH	1	1	UG 5 Gear
	PF 1130 61	Step Pillion RH	1	1	
3	39 1298 04	Screw Hex. Socket M8x1.25x35	2	2	
4	JB 2312 06	Bolt Socket Head	2	2	
5	PF 2312 01	Leg Guard	1	1	
6	JA 2312 01	Hook Leg Guard	1	1	
7	JA 2312 02	Spacer Leg Guard	1	1	
8	39 0798 15	Nut Hex with Falnge M6	2	2	



Painted Parts and Decals

No.	Part No.	Description	Drum	Disc	Remarks
1	PF 1812 09	Wind Shield	1	1	
2	52 PF05 89	Tank Ebony Black Wh Dcl	1	1	
	52 PF05 90	Tank Electron Blue Wh Dcl	1	1	
	52 PF06 32	Tank Passion Red Wh Dcl	1	1	
3	52 PF05 84	Sd Cvr LH Pla Sil Wh El. Blue	1	1	
	52 PF05 81	Sd Cvr LH Pla Sil Wh Eb Blk Dcl	1	1	
	52 PF06 30	Sd Cvr LH Pla Sil Wh P red Dcl	1	1	
4	52 PF05 85	Sd Cvr RH Pla Sil Wh El. Blue	1	1	
	52 PF05 82	Sd Cvr RH Pla Sil Wh Eb Blk Dcl	1	1	
	52 PF06 31	Sd Cvr RH Pla Sil Wh P red Dcl	1	1	
5	PF 7401 X3	Cowling Painted	1	1	Ebony Black Electron Blue Passion Red
	PF 7401 3E	Cowling Painted	1	1	
	56 PF1T 4R	Cowling Painted	1	1	
6	36 PF00 76	Kit Tank Decal Electron Blue	1	1	
	36 PF00 78	Kit Tank Decal Ebony Black	1	1	
	36 Pf00 81	Kit Tank Decal Passion Red	1	1	
7	36 PF00 77	Kit Side Cover Decal Electron Blue	1	1	
	36 PF00 79	Kit Side Cover Decal Ebony Black	1	1	
	36 PF00 82	Kit Side Cover Decal Passion Red	1	1	

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
1	36JZ0001	Valve Kit	JZ511200 JZ511201	Valve Intake Valve Exhaust	1 1
2	36JZ0004	Valve Repair Kit	39201719 DG101029 JA511203 28101129 JZ511202	Seat Valve Stem Cotter Valve Retainer Valve Spring Seat Valve Spring Spring Washer	2 2 2 2 2
3	36JE0003	Kit Guide Cam Chain	JW541012 JA521002	Guide Cam Chain (Slack Side) Guide Cam Chain (Tight Side)	1 1
4	36DU1007	Boss Kick Set	30101233 30101234 30101236 30101235 39085517	Boss Kit Spring Ball Steel Pin E - Type Clip	1 1 1 1 1
5	36PF0021	Kit Jet BM 150	JZ581234 JZ581219 JZ581218 JE581205	Needle Jet Holder Needle Jet Jet Main Jet Pilot	1 1 1 1
6	DH121169	Pilot Screw Kit	DH121131 DH121130 DH121186 DH121187 DH121188	Screw Adjuster 'O' - Ring Spring Compr Coil Plain Washer 'O' - Ring	1 1 1 1 1
7	36JZ0016	Idling Screw Kit	JZ581217 DH121130 CB121044	Screw Stop 'O' - Ring Spring Compression	1 1 1

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
8	36PF0022	Kit Piston Valve BM 150	PF581206 DD121054 JZ581211 DD121055 JZ581223 PF581208 PF581207	Valve Piston E-Ring Holder Assly Magnet Spring Compression Packing Jet Needle Ring	1 1 1 1 1 1 1
9	36PF0024	Kit Carburetor Gasket/O Ring	JA581232 DH121130 DH121088 DH121118 JA581238	Gasket Float Chamber 'O' - Ring Idling Screw O Ring Air Screw 'O' Ring Drain screw 'O' Ring TPS	1 2 2 1 1
10	36PF0023	Kit Choke Plunger BM 150	- - PF581205 DH121071 Dd121058 CF121004	Plunger Assembly Guide Holder Lever Assembly Choke Cap Spring Choke Plunger O Ring Choke Plunger	1 1 1 1 1 1
11	36DS1801	Holder Handle Set	DS181019 DS181006	Holder Handle Holder Handle	2 2
12	36PF0010	Kit Chain Sprocket BM 150	DX151023 JZ551004 JV141004	Sprocket Hub (42T) Sprocket Drive (14T) Chain 122 Link	1 1 1
13	36JZ0008	Starter Clutch Repair Kit	JA621411 DH101163 DH101164 DJ101109	Bush Spring Starter Clutch Roller Clutch Spring Bush For Spring Starter Clutch	5 5 5 5

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
14	36JZ0003	Set Primary Drive & Driven	JZ551403 JZ531006	Housing Complete Clutch HTTS Gear Primary Drive	1 1
15	36PF0009	Kit Friction Plate BM 150	JV551402	Plate Friction Clutch	5
16	36PF0002	Kit Block-Piston BM 150	PF521007 PF521205	Assly Cylinder Block Piston Assly	1 1
17	36PF0011	Case Chain Kit	PF181202 Pf181200	Case Chain Upper Assly. Case Chain Lower Assly.	1 1
18	36DK0020	Kit Outer Tube	DJ181089 DJ181088 DS181072 DS181070	Seal Dust Stopper Seal Oil Washer Guide Bush Guide Bush	2 2 2 2
19	36DK0037	Kit Mirror Holder	39118415 DL191014 30191017 39019811 39072504	Nut - Nylock :- M5 X 0.8 Stud - Lever Handle Nut Washer - Plain Bolt - Hexagon :- M6 X 1	1 1 1 1 1
20	36PF0076	Kit Tank Dcl Electron Blue	PF233132 PF233133	Tank Dcl LH El. Blue Tank Dcl RH El. Blue	1 1
21	36PF0078	Kit Tank Dcl Ebony Black	PF233134 PF233135	Tank Dcl LH Ebony Black Tank Dcl RH Ebony Black	1 1
22	36PF0081	Kit Tank Dcl Passion Red	PF233140 PF233141	Tank Dcl LH Passion Red Tank Dcl RH Passion Red	1 1
23	36PF0077	Kit S Cover Electron Blue	PF233136 PF233137	S Cover Dcl LH Electron Blue S Cover Dcl RH Electron Blue	1 1

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
24	36PF0079	Kit S Cover Ebony Black	PF233138 PF233139	S Cover Dcl LH Ebony Black S Cover Dcl RH Ebony Black	1 1
25	36PF0082	Kit S Cover Passion Red	PF233142 PF233143	S Cover Dcl LH Passion Red S Cover Dcl RH Passion Red	1 1
26	36PF0001	KIT ASLY CYL HEAD Bm150	39166005 PF511016	STUD - M8 HEAD CYLINDER	2 1
27	36PF0116	KIT PISTON RING BM150 FI	JZ521204 JZ521206 JE521214	RING TOP PISTON DIA 56 RING OIL PISTON DIA 56 RING 2ND CHROME PLATED	1 1 1
28	36PF0005	KIT ASLY C CASE RH	PF541009 JA541011 PF541018 31101064	CRANKCASE RH BM150 4 SPD NEEDLE ROLLER BEARING Hk12 BUSHING DRUM BM150 4 SPD PLUG	1 1 1 1
29	36PF0004	KIT ASLY C CASE LH	PF541007 JA541005 39256220 JZ541005	CRANKCASE LH Bm150 BUSH BENDIX BEARING - NEEDLE ROLLER NOZZLE OIL JET	1 1 1 1
30	36PF0008	KIT ASLY CL COVER	PF541205 DG101418 DS101215	COVER CLUTCH GAUGE CLIP - WIRE	1 1 1
31	36PF0007	KIT ASLY MAG COVER	PF541201 JA541005	COVER MAGNETO (BM100)SS BUSH BENDIX	1 1
32	36JZ0003	KIT DRIVE & DRIVEN	JZ551403 JZ531006	CLUTCH HSG ASSLY HTTS GEAR PRIMARY DRIVE	1 1



Page No.	Fig. No.	Old Part No.	New Part No.	Description	Update Date	Remarks
46	6	-----	PF231417	Frame Grip	22.01.19	Added Ref.Cir.IB-388
74	17	-----	PF151032	Grip Assembly RH	08.09.20	Added Ref.Cir.IB-398
88	1	-----	PF161237	Cable Throttle	08.09.20	Added Ref.Cir.IB-398
36	17	-----	JE591280	Gasket Exhaust	30.12.20	Added Ref.Cir.IB-418
98	3	-----	PF402262	Harness Wiring	27.01.21	Added
98	12	-----	AK201012	Fuse - 10a (Blade Type)	27.01.21	Added
98	12	-----	AP201025	Fuse 15a (Blade Type)	27.01.21	Added
78	17	-----	DE181033	Cylinder Complete Fork	13.09.21	Deleted
52	4	-----	PF122050	Shock Absorber Rear	01.04.22	Added Ref.Cir.IB-451
52	4	-----	PF122056	Shock Absorber Rear	01.04.22	Added Ref.Cir.IB-451
56	8	-----	PF181447	Fender Front Rear	01.04.22	Added Ref.Cir.IB-451
56	11	-----	PF181448	Brace Fender Front Rear	01.04.22	Added Ref.Cir.IB-451
58	1	-----	PF113225	Stand Center	01.04.22	Added Ref.Cir.IB-451
58	3	-----	KHAA3225	Pin Cotter	01.04.22	Added Ref.Cir.IB-451
58	4	-----	JZ113205	Spring Tension	01.04.22	Added Ref.Cir.IB-451
58	5	-----	PF113226	Stand Side	01.04.22	Added Ref.Cir.IB-451
66	2	-----	PF131835	Hose Assembly	01.04.22	Added Ref.Cir.IB-451
66	4	-----	GL131827	Bolt Banjo	01.04.22	Added Ref.Cir.IB-451
68	1	-----	PD131853	Caliper Assembly Front	01.04.22	Added Ref.Cir.IB-451
78	1	-----	PF121124	Fork Front	01.04.22	Added Ref.Cir.IB-451
78	1	-----	PF121144	Fork Front	01.04.22	Added Ref.Cir.IB-451
88	3	-----	DZ191014	Cable - Speedometer W/o Bent Tube	01.04.22	Added Ref.Cir.IB-451
88	5	-----	PF161245	Cable Brake	01.04.22	Added Ref.Cir.IB-451



Page No.	Fig. No.	Old Part No.	New Part No.	Description	Updation Date	Remarks

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
14151033	23	26	30191035	11	72
14151033	15	30	30191036	13	72
15161069	2	90	30191038	3	72
18201044	5	94	30191048	24	76
20201029	5	94	30201069	12	96
22150241	4	32	30201104	11	98
24121069	14	34	30211005	2	56
24121365	7	34	31101173	3	12
30101142	4	26	31181099	18	78
30101195	8	28	31201001	5	96
30121004	20	34	31201081	5	24
30141031	3A	82	35161060	18	92
30151011	19	70	36DJ4032	9	68
30151032	7	62	36DJ4033	10	68
30151033	6	62	36DK0020	2	78
30151033	6	64	36DK0037	21	76
30151035	23	62	36DS1401	1	84
30151038	13	62	36DS1502	22	62
30151038	20	70	36DS1801	13	74
30151041	19	64	36DU1007	3	32
30151041	12	86	36DU1901	11	74
30151069	10	62	36DZ2008	3	50
30151069	16	70	36JE0003	6	8
30151075	7	62	36JH0009	3	32
30151075	13	70	36JZ0001	4	6
30151095	20	72	36JZ0003	7	12
30151118	20	62	36JZ0003	16	30
30151118	16	64	36JZ0004	5	6
30171022	16	54	36JZ0008	6	42
30181026	3	78	36JZ0016	5	34
30181029	20	78	36PD0043	4	68

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
36PF0001	1	4	39042215	23	76
36PF0002	5	10	39045411	11	52
36PF0004	1	24	39055302	10	52
36PF0005	2	22	39059417	12	8
36PF0007	1	28	39069415	18	72
36PF0008	1	26	39070815	21	72
36PF0009	5	30	39071411	2	52
36PF0010	2	70	39072009	6	50
36PF0011	1	90	39072211	19A	70
36PF0021	4	34	39073212	19	62
36PF0022	12	34	39073817	6	32
36PF0023	19	34	39074701	9	24
36PF0024	13	34	39076101	2	82
36PF0076	6	104	39078408	18	54
36PF0077	7	104	39078912	8	52
36PF0078	6	104	39078912	17	72
36PF0079	7	104	39078912	13	78
36Pf0081	6	104	39079708	3	58
36PF0082	7	104	39079708	8	72
36PF0107	11	12	39079815	10	86
36PF0116	3	10	39079815	17	92
36PF0159	5	10	39079815	8	102
36PF0160	1	4	39080115	3	70
39019811	5	72	39080511	7	72
39019811	10	72	39080708	19	72
39021111	18	56	39080808	6	72
39024011	13	30	39081715	8	20
39024211	24	62	39084914	17	42
39024211	18	64	39093915	13	52
39029215	16	52	39098308	6	84
39042215	8	58	39098717	3	14

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
39098717	3	16	39174004	10	22
39099206	2	18	39175904	17	24
39099311	5	32	39176511	19	92
39099906	12	24	39177304	13	36
39099906	24	26	39177902	15	36
39099906	4	40	39178924	5	84
39100006	2	10	39181304	4	78
39100006	6	22	39181304	14	78
39100006	11	24	39188020	15	8
39101321	25	62	39194304	11	44
39101321	17	64	39194304	17	56
39104119	3	26	39194304	25	76
39105411	7	84	39195604	8	96
39106204	9	34	39196404	14	22
39106504	2	28	39197015	6	48
39107504	28	70	39197015	9	92
39121111	4	46	39197215	13	96
39122515	7	94	39198104	20	14
39129804	3	102	39201719	6	6
39154011	16	72	39214124	3	92
39155304	11	30	39217924	3	82
39155304	12	74	39219019	7	24
39155604	7	46	39220011	12	30
39156121	6	88	39220011	4	42
39167121	20	26	39223801	20	92
39167304	11	8	39229515	3	38
39167304	22	26	39231204	5	48
39167404	3	44	39234911	3	52
39167704	16	36	39236615	7	52
39168904	2	98	39240817	12	32
39171519	4	24	39242911	6	96

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
39243015	3	96	52PF0631	4	104
39244311	9	26	52PF0632	2	104
39248104	10	54	52PF1735	1	28
39248415	8	82	56DY5E3Q	2	22
39249211	5	38	56JV1V3Q	1	26
39253921	8	4	56PF1T4R	5	104
39256220	2	24	59040006	7	78
39256611	30	70	59040014	14	44
39256711	4	70	59040017	7	48
39258204	8	92	59040038	2	2
39260011	4	30	59040038	11	22
39265912	11	54	59040038	16	24
39266921	13	8	59040038	17	26
39268320	16	8	59040038	4	28
39270411	7	20	59110008	2B	12
39272204	6	38	59120003	2A	12
39272315	3	48	59150003	11	62
39275404	4	38	59150014	1	12
39276501	10	96	59210023	18	24
52JA0027	9	22	59210024	17	14
52JA0029	12	22	59210024	17	16
52JV0106	5	52	AA121045	18	36
52JZ0264	1	20	AK201012	12	98
52PF0219	5	52	AP201025	12	98
52PF0581	3	104	CB101114	2	38
52PF0582	4	104	CB121042	8	34
52PF0584	3	104	CF111019	7	44
52PF0585	4	104	CL201023	10	92
52PF0589	2	104	CL201023	2	96
52PF0590	2	104	CL201042	7	86
52PF0630	3	104	CS101128	9	8

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
CS201026	17	98	DF161426	3	36
DD101062	10	8	DG101029	3	6
DD101097	13	32	DG101418	7	26
DD111011	9	44	DG151089	1	68
DD111018	7	44	DG161121	2	84
DD111048	8	44	DG161124	9	58
DD121181	19	26	DG161224	12	54
DD161078	22	72	DH101048	5	8
DD161437	14	56	DH101380	8	22
DD191142	15	74	DH101380	8	42
DD201011	3	56	DH101380	4	44
DD201011	4	96	DH101388	15	26
DD201170	22	76	DH101392	7	8
DE151006	5	64	DH101509	10	20
DE151008	2	64	DH101607	9	38
DE151011	13	64	DH101647	8	64
DE151011	11	86	DH101648	14	30
DE151012	3	64	DH101781	2	42
DE151043	8	68	DH101784	6	24
DE151045	2	68	DH121038	7	4
DE151046	5	68	DH121038	14	36
DE151047	6	68	DH121169	3	34
DE151048	3	68	DH151029	19	52
DE191028	14	66	DH151029	15	72
DE191029	13	66	DH151057	3	60
DE191030	10	66	DH161066	6	58
DE191033	6	66	DH161121	4	58
DE191043	1	66	DH161194	5	54
DF161102	7	58	DH161283	3	90
DF161252	9	96	DH171019	10	64
DF161413	4	54	DH171019	27	70

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DH181014	5	50	DJ201108	5	88
DH181025	11	78	DJ201109	12	66
DH191037	8	86	DJ221003	3	74
DJ141008	8	84	DJ221004	4	74
DJ151033	11	70	DK101386	4	8
DJ151035	5	70	DK141041	10	82
DJ151036	14	52	DK151094	14	70
DJ151037	15	52	DL181009	23	92
DJ151041	1	62	DL181010	2	92
DJ151041	1	64	DM201026	11	96
DJ151047	17	52	DM221013	1	100
DJ151053	1	70	DP101165	4	10
DJ151077	1	60	DP121025	7	2
DJ151092	18	70	DP121025	8	36
DJ161069	9	56	DP161101	15	96
DJ181051	22	78	DP161163	17	54
DJ181052	24	78	DP161170	8	54
DJ181065	7	56	DP171006	6	52
DJ181085	25	78	DP211009	8	46
DJ181087	2A	78	DS101117	8	32
DJ181115	4	50	DS101154	6	12
DJ191025	4	66	DS101215	8	26
DJ191026	5	66	DS101355	20	16
DJ191028	7	66	DS109905	14	8
DJ191029	8	66	DS121126	7	36
DJ191030	9	66	DS141009	1	82
DJ191056	11	66	DS151056	3	62
DJ191057	3	66	DS151056	11	64
DJ191081	6	74	DS151057	29	70
DJ191083	5	74	DS151060	4	62
DJ201051	24	92	DS151068	7	70

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DS151069	18	70	DS201025	9	98
DS151069	31	70	DS201082	6	98
DS151073	8	70	DU101213	19	14
DS151089	12	62	DU101213	19	16
DS151089	19	70	DU161102	3	84
DS151090	21	70	DU181021	1	74
DS151091	14	62	DU191003	17	74
DS151092	16	62	DU191009	8	74
DS151094	17	62	DU201016	6	94
DS151094	26	70	DU201029	4	92
DS161125	10	56	DX151022	25	70
DS161150	9	28	DZ191014	3	88
DS181005	10	78	FD101078	3	40
DS181006	17	78	FD211006	2	46
DS181007	18	74	FD211007	3	46
DS181008	19	74	GF201053	12	98
DS181012	19	78	GL131827	4	66
DS181015	8	78	GL621414	1	42
DS181016	9	78	JA113201	2	58
DS181018	2	50	JA113202	5	58
DS181022	2a	74	JA113402	2	48
DS181070	26	78	JA113403	4	48
DS181072	27	78	JA121003	12	52
DS181084	6	78	JA131606	26	62
DS191035	4	72	JA131606	20	64
DS191038	20	74	JA231201	6	102
DS191052	7	74	JA231202	7	102
DS191052	14	74	JA351602	11	42
DS201019	5	92	JA351606	9	42
DS201020	6	92	JA351608	12	42
DS201021	7	92	JA351609	13	42

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JA351618	14	42	JA551002	4	16
JA351619	16	42	JA551004	7	14
JA351624	15	42	JA551004	7	16
JA351626	9	42	JA551008	15	14
JA351627	11	42	JA551008	15	16
JA401801	8	98	JA551009	16	14
JA511008	4	2	JA551009	16	16
JA511011	6	2	JA551406	3	30
JA511011	9	36	JA551414	6	30
JA511028	2	4	JA551415	8	30
JA511211	1	6	JA551419	7	30
JA511216	2	8	JA561002	3	18
JA521015	6	10	JA561207	4	20
JA531012	8	12	JA561208	5	20
JA531015	9	12	JA561209	6	20
JA541005	8	24	JA581009	5	36
JA541005	6	28	JA581011	12	36
JA541010	5	22	JA581012	6	36
JA541011	4	22	JA581221	6	34
JA541012	13	22	JA581223	2	34
JA541016	2	40	JA581291	18	34
JA541028	13	44	JA581314	15	34
JA541034	10	24	JA581406	5	4
JA541205	3	28	JA621001	7	32
JA541211	11	26	JA621002	9	32
JA541212	16	26	JA621006	11	32
JA541216	14	26	JA621201	1	32
JA541219	21	26	JA621206	2	32
JA541225	12	26	JA621206	15	32
JA541233	7	28	JA621406	5	42
JA551002	4	14	JA621414	1	42

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JB113005	7	38	JE551205	10	16
JB122003	9	52	JE551206	11	16
JB122016	1	52	JE551208	21	16
JB131017	1	62	JE551215	14	16
JB131018	2	62	JE551216	12	16
JB151012	15	92	JE551401	6	26
JB151013	16	92	JE551408	6	26
JB161002	12	72	JE561005	3	18
JB181220	4	90	JE591002	17	36
JB231206	4	102	JE591280	17	36
JB401400	9	74	JE621003	14	32
JB531021	10	12	JE621004	16	32
JB581001	10	36	JF401807	6	98
JB581202	10	34	JF401808	20	98
JB581204	11	34	JG351016	10	44
JD402217	23	72	JG571024	13	24
JD511010	3	2	JH171017	7	82
JD531004	12	12	JH351603	7	42
JD551400	2	30	JH521007	1	10
JD561004	6	18	JH541015	15	22
JD561006	5	18	JH561200	4	20
JD561011	4	18	JH561404	11	20
JD561204	5	20	JH621403	3	42
JE531001	5	12	JH621407	5a	42
JE541008	14	32	JK113008	15	54
JE541038	19	24	JK351600	10	98
JE541214	10	26	JK541212	13	26
JE551200	6	16	JK541214	10	28
JE551201	5	16	JL541227	7	26
JE551202	2	16	JL541227	15	66
JE551203	9	16	JN131800	2	66

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JN131807	7	64	JZ131206	3	60
JN131812	9	62	JZ161025	26	76
JN131812	17	70	JZ161210	3	88
JN402000	12	44	JZ401405	10	74
JV161014	9	72	JZ401408	16	74
JV171001	4	84	JZ511004	1	8
JV181408	15	56	JZ511016	3	4
JV181410	16	56	JZ511021	1	2
JV191001	1	46	JZ511203	2	6
JV191003	9	46	JZ541237	9	28
JV351204	5	44	JZ551004	18	14
JV401602	1	98	JZ551004	18	16
JV401801	7	98	JZ551008	8	16
JV402204	13	98	JZ551010	1	16
JV402205	14	98	JZ551204	14	14
JV521003	8	8	JZ551205	13	14
JV541006	15	24	JZ551205	13	16
JV541205	21	26	JZ551210	22	16
JV541208	5	26	JZ561002	7	18
JV541209	18	26	JZ561416	9	20
JV541212	5	28	JZ581216	17	34
JV541225	2	26	JZ581220	16	34
JW122004	14	72	JZ621000	10	32
JW131601	22	70	JZ621405	3	42
JW131807	7	68	KADD0610	16	98
JW181229	14	92	KADD0614	30	80
JW181232	13	92	KADD0822	9	54
JW402001	12	44	KADD0885	8	48
JW561206	2	20	KADF0625	4	56
JW561208	3	20	KADF0630	13	56
JZ113205	4	58	KADF0820	12	56

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
KADF0822	2	54	PA402256	14	98
KADT0612	6	56	PA511039	5	2
KAEF0630	15	62	PA561209	4	20
KAEF0630	23	70	PA621007	7	32
KBBA0408	18	62	PA621008	10	32
KBBA0408	15	64	PA621203	1	32
KBRC3513	18	52	PD131853	1	68
KCMB0605	14	96	PD511229	3	8
KDAA1222	9	64	PF111000	1	50
KDDB0408	14	64	PF113000	1	54
KDDB1018	20	52	PF113001	3	54
KHAA3225	3	58	PF113002	6	54
KHAA3230	3	58	PF113003	7	54
KHBA0828	21	52	PF113008	1	102
KPBB6202	5	62	PF113009	2	102
KPBB6301	8	62	PF113028	4	54
KPBB6301	4	64	PF113058	6	54
KPBC6004	6	70	PF113059	7	54
KPBC6202	12	70	PF113060	13	54
KPBC6302	15	70	PF113060	1	102
KPBF6203	3	22	PF113061	14	54
KPBF6203	3	24	PF113061	2	102
LAC00021	5	46	PF113202	1	58
LAD00011	10	42	PF113224	1	58
LAD00131	12	20	PF113225	1	58
LAD00131	15	98	PF113226	5	58
LCB00005	9	70	PF113402	1	48
LDB00001	21	62	PF121017	5	78
LJA00004	14	24	PF121018	15	78
PA351027	1	44	PF121019	16	78
PA402248	13	98	PF121024	21	78

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
PF121025	12	92	PF161002	1	72
PF121028	23	78	PF161209	4	88
PF121037	15	78	PF161212	2	88
PF121039	16	78	PF161213	5	88
PF121054	29	80	PF161217	1	88
PF121080	1	78	PF161237	1	88
PF121083	28	80	PF161245	5	88
PF121085	12	78	PF171800	4	82
PF121116	31	80	PF171803	9	82
PF121117	32	80	PF181209	22	92
PF121118	1	78	PF181209	1	104
PF121119	1	78	PF181211	21	92
PF121120	31	80	PF181430	1	56
PF121121	32	80	PF181431	5	56
PF121124	1	78	PF181432	8	56
PF121144	1	78	PF181433	11	56
PF122004	4	52	PF181447	8	56
PF122030	5	52	PF181448	11	56
PF122033	4	52	PF191000	1	46
PF122050	4	52	PF231201	5	102
PF122056	4	52	PF231401	7	96
PF131008	2	60	PF231405	6	46
PF131033	1	60	PF231417	6	46
PF131208	24	70	PF232601	2	74
PF131215	4	60	PF232605	2	74
PF131220	10	70	PF232605	5	82
PF131612	12	64	PF351003	1	44
PF131811	27	62	PF351004	2	44
PF131835	2	66	PF351069	2	44
PF151032	17	74	PF351201	6	44
PF161001	2	72	PF351242	6	44

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
PF351600	7	42	PF511021	8	2
PF351800	18	98	PF531000	4	12
PF401000	1	92	PF531033	4	12
PF401001	1	94	PF541018	7	22
PF401002	2	94	PF541109	1	24
PF401003	3	94	PF541217	2	26
PF401004	4	94	PF541217	10	28
PF401005	1	96	PF541249	10	28
PF401009	11	92	PF541254	21	26
PF401016	1	92	PF541255	18	26
PF401403	5	98	PF541286	3	28
PF401404	4	98	PF541287	5	28
PF401417	16	74	PF551002	1	14
PF402210	11	96	PF551003	8	14
PF402213	3	98	PF551200	6	14
PF402222	17	98	PF551201	5	14
PF402254	3	98	PF551202	2	14
PF402261	3	98	PF551203	10	14
PF402262	3	98	PF551204	11	14
PF402400	1	86	PF551205	12	14
PF402401	2	86	PF551206	9	14
PF402402	4	86	PF551403	1	30
PF402403	6	86	PF551405	9	30
PF402404	9	86	PF551406	10	30
PF402405	3	86	PF561000	1	18
PF402406	5	86	PF561002	5	18
PF402416	1	86	PF561010	1	18
PF402600	6	82	PF561200	1	20
PF403400	19	98	PF561203	5	20
PF501004	1	22	PF571000	1	40
PF501108	1	22	PF571001	5	40

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
PF581002	2	36			
PF581003	1	36			
PF581012	4	36			
PF581019	11	36			
PF581200	1	34			
PF581268	1	34			
PF581401	4	4			
PF581402	6	4			
PF591017	1	38			
PF591043	10	38			
PF591045	8	38			
PF591059	1	38			
PF621416	10	24			
PF74013E	5	104			
PF7401X3	5	104			