
Pulsar NS 200 (Peru)

Pulsar NS 200 (Peru)


1. Cover Cylinder Head



Sr. No.	Part No.	Description	QTY.	Remarks
1	JG511022	BOLT SPECIAL	4	
2	JG511021	WASHER	4	
3	JL511041	COVER CYLINDER HEAD	1	
4	JL511042	GASKET HEAD COVER	1	

Pulsar NS 200 (Peru)


2. Cylinder Head



Sr. No.	Part No.	Description	QTY.	Remarks
1	JG541068	BOLT FLANGED STEP M10X1.25	4	
2	LDA00008	WASHER PLAIN	4	
3	JL511009	M6 STUD BOLT	2	
4	DT511097	HEAD CYLINDER	1	
5	DK101225	SWITCH PRESSURE OIL	1	
6	DK101340	O RING (OIL COOLER PIPE)	1	
7	JG351400	SENSOR TEMPERATURE	1	
8	JG511046	BOLT STUD M8X1.25	2	
9	KAEQ0620	BOLT FLANGE SMALL-M6X1XL20XDACRO	2	
10	JL511029	COVER THERMOSTAT	1	
11	JL601237	THERMOSTAT	1	
12	39260801	SCREW - GRUB :- M5 X 0.8 X 7	1	

Pulsar NS 200 (Peru)


2. Cylinder Head



Sr. No.	Part No.	Description	QTY.	Remarks
13	JL511112	SLEEVE SPARK PLUG	1	
14	KJAC1824	O RING	1	
15	39128321	RING - O	1	
16	JL511022	GASKET HEAD CYLINDER	1	
17	LBC00002	SCREW CSK CROSS M6X1	3	
18	JL581039	PIPE INTAKE	1	
19	JG581407	RING O	1	

Pulsar NS 200 (Peru)


3. Valve



Sr. No.	Part No.	Description	QTY.	Remarks
1	39201719	SEAL - OIL	4	
2	JL511010	VALVE INTAKE	2	
3	JL511011	VALVE EXHAUST	2	
4	DT511261	ROCKER ARM ASSEMBLY INTAKE	1	
5	DT511262	ROCKER ARM ASSEMBLY EXHAUST	1	
6	JL511114	SHAFT ROCKER ARM	2	
7	JL511115	PLATE STOPPER	1	
8	LAE00042	BOLT FLANGED-M6X1	2	
9	DG101029	COLLET	8	
10	36JL0011	KIT VALVE REPAIRE-P200	1	
11	DH101295	WASHER - WAVE (ROCKER ARM)	2	
12	39244011	WASHER (SPRING STEEL)	4	

Pulsar NS 200 (Peru)


4. Camshaft / Tensioner



Sr. No.	Part No.	Description	QTY.	Remarks
1	JL511271	CAMSHAFT ASSEMBLY	1	
2	36JL0001	KIT CHAIN GUIDE-P200	1	
3	JL531003	PLATE GUIDE CHAIN SLACK	1	
4	KEBB3515	CIRCLIP INTERNAL	1	
5	JL511250	SPACER CAMSHAFT	1	
6	JL511231	SPROCKET CAMSHAFT	1	
7	JG511269	BOLT FLANGED M8X1	1	
8	JL511230	SILENT CHAIN	1	
9	JC101034	TENSIONER ASSEMBLY (JC)	1	
10	39266921	RING - O (ID 10.15 X 1.5)	1	
11	KAEQ0620	BOLT FLANGE SMALL-M6X1XL20XDACRO	2	
12	CS101128	Gasket	1	

Pulsar NS 200 (Peru)


4. Camshaft / Tensioner



Sr. No.	Part No.	Description	QTY.	Remarks
13	JG511270	BOLT FLANGED M6X1	1	
14	DH101392	PRECOATED TENSIONER PIVOT BOLT - DH10101	1	

Pulsar NS 200 (Peru)


5. Cylinder Block and Piston



Sr. No.	Part No.	Description	QTY.	Remarks
1	36JL0007	KIT BLOCK & PISTON-P200	1	
2	JL521200	PISTON ASSEMBLY	1	
3	JU521210	PIN PISTON	1	
4	JU521212	RING SNAP	2	
5	39218106	PIN - HOLLOW DOWEL :- 14 X 20	2	
6	JG521008	GASKET BLOCK CYLINDER	1	
7	36JU0001	KIT RING SET KTM 200	1	

Pulsar NS 200 (Peru)


6. Crankshaft



Sr. No.	Part No.	Description	QTY.	Remarks
1	36JU0036	KIT CRANK SHAFT ASSLY	1	
2	39193120	BEARING - BALL :- 28 X 68 X 18	2	
3	39220307	PIN - PARALLEL	2	
4	JG531040	NUT M28X1.5	1	
5	LDH00002	WASHER CONICAL	1	
6	JG531041	BALANCER DRIVE GEAR	1	
7	LCD00001	NUT SPROCKET DRIVE LOCK	1	
8	39220011	WASHER - PLAIN (PRIMARY DRIVE GEAR)	1	
9	JL531006	SPROCKET CRANKSHAFT	1	
10	36DT0055	KIT CL HOUSING & PRIMARY GEAR	1	
11	JG531031	SPACER CRANKSHAFT	1	
12	KFAB4050	KEY WOODRUFF	3	

Pulsar NS 200 (Peru)


6. Crankshaft



Sr. No.	Part No.	Description	QTY.	Remarks
13	JF531014	BOLT CONROD	2	
14	JU531021	BUSH BIG END	2	

Pulsar NS 200 (Peru)


7. Transmission



Sr. No.	Part No.	Description	QTY.	Remarks
1	JG551027	SHAFT INPUT T/M COMP	1	
2	39215811	WASHER - PLAIN	1	
3	JG551213	GEAR 6TH DRIVE	1	
4	JG551013	BUSH 6TH DRIVE / BUSH 2ND DRIVEN	2	
5	JP551012	WASHER -ID 16XOD 26XTHK 1	4	
6	BF551037	RING SNAP OUTPUT	4	
7	JG551214	GEAR THIRD-FOURTH DRIVE	1	
8	JG551220	GEAR FIFTH DRIVE	1	
9	JG551227	GEAR 2ND DRIVE	1	
10	JG551022	WASHER PLAIN 2ND GEAR I/P SHAFT	1	
11	JU551003	SHAFT OUTPUT-PLUG	1	
12	DH101235	CIRCLIP	2	

Pulsar NS 200 (Peru)


7. Transmission



Sr. No.	Part No.	Description	QTY.	Remarks
13	39216611	WASHER - PLAIN	1	
14	JU551201	GEAR DRIVEN SECOND	1	
15	JP551225	GEAR FIFTH DRIVEN	1	
16	JP551224	GEAR THIRD DRIVEN	1	
17	JG551021	WASHER PLAIN-ID 20.2XOD30XT 2.15	1	
18	JG551215	GEAR 4TH DRIVEN	1	
19	JP551226	GEAR SIXTH DRIVEN	1	
20	JG551225	GEAR 1ST DRIVEN (G2)	1	
21	JG551000	BUSH IST DRIVEN	1	
22	39215911	WASHER - PLAIN	1	
23	JG551031	COLLAR SPROCKET	1	
24	DK101352	O-RING SPROCKET COLLAR(17.5*1.5)	1	

Pulsar NS 200 (Peru)


7. Transmission



Sr. No.	Part No.	Description	QTY.	Remarks
25	36JL0184	KIT CHAIN SPROCKET EUIV	1	
26	JG551019	PLATE DRIVE SPROCKET	1	
27	LAE00017	BOLT FLANGED M6X1	2	
28	JP551011	COLLAR	1	

Pulsar NS 200 (Peru)


8. Change Drum / Shift Fork



Sr. No.	Part No.	Description	QTY.	Remarks
1	JG561011	DRUM COMPLETE GEAR SHIFT	1	
2	EC561023	SPRING GEAR SWITCH INDICATOR	1	
3	39260607	PIN - PARALLEL	1	
4	JG561010	SPACER-GUIDE GEAR SHIFT	1	
5	JG561222	GUIDE GEAR SHIFT	1	
6	DH101389	PRECOATED PAN SCREW M6 X 20 - 39119704	1	
7	JG561012	FORK GEAR SHIFT INPUT	1	
8	JP561003	FORK GEAR SHIFT OUTPUT	2	
9	JG561016	SHAFT GEAR SHIFT FORK_G2	1	
10	JG561225	SHAFT GEAR SHIFT FORK OUTPUT	1	
11	JG561215	COMPRESSION SPRING	2	
12	JG561008	GEAR INDICATOR PIN	1	

Pulsar NS 200 (Peru)


9. Gear Change Mechanism



Sr. No.	Part No.	Description	QTY.	Remarks
1	JL561222	LEVER ASSEMBLY CHANGE	1	
2	JL561414	ARM ASSEMBLY CHANGE	1	
3	52JL2033	K4 BS6 ASSEMBLY TIE ROD(JL561412)WITHNUT	1	
4	KCAC0605	NUT HEX THICK	1	
5	LCA00026	NUT HEX M6X1 LH	1	
6	DH101509	DAMPER	1	
7	52JL2034	K4BS6 ASSLYLEVER COMPCHANGEGEAR JL561413	1	
8	JL561409	BOLT GEAR CHANGE LEVER	1	
9	01100905	RING - O	2	
10	JL561410	WASHER PLAIN	1	
11	DT561206	LEVER GEAR SHIFT ASSLY COMP	1	
12	JG561215	COMPRESSION SPRING	1	

Pulsar NS 200 (Peru)


9. Gear Change Mechanism




Sr. No.	Part No.	Description	QTY.	Remarks
13	JG561217	BUSH-TORSION SPRING	1	
14	JG561232	SPRING TORSION.	1	
15	JG561216	WASHER 14X30X1.5	1	

Pulsar NS 200 (Peru)


10. Engine Assembly / Crankcase RH



Sr. No.	Part No.	Description	QTY.	Remarks
1	JL501089	ENGINE ASSEMBLY	1	
2	36DT0079	KIT CRANKCASE RH BSIV	1	
3	39193120	BEARING - BALL :- 28 X 68 X 18	1	
4	JY541047	STOPPER I/P SHAFT BEARING	1	
5	LAD00077	BOLT FLANGE-M6X1XL16XBLKXPRECOAT	1	
6	JG601007	SEAL OIL	2	
7	52JL1890	BALANCER ASSEMBLY-JL531205 WITH DOME NUT	1	
8	39260220	BEARING - BALL 6202/HN3	1	
9	AA101437	SCREW :- PRE-COATED	1	
10	JG541059	PLATE STOPPER BEARING DRUM	1	
11	39260120	BEARING - BALL :- 61905 (25 X 42 X 9)	1	
12	LBB00006	SCREW PAN CROSS-M5X0.8XL 10XBRT	3	




Sr. No.	Part No.	Description	QTY.	Remarks
13	JU541005	PLATE BREATHER	1	
14	59200028	BALANCER RH BEARING 6204N (20*47*14)	1	
15	JG561204	BOLT STOPPER DRUM	1	
16	JG561205	WASHER DRUM STOPPER	1	
17	JG561009	STOPPER DRUM COMP	1	
18	LDB00050	WASHER PLAIN-ID 6XOD 14XTHK 1.2	1	
19	JG561226	SPRING STOPPER DRUM	1	
20	39256220	BEARING - NEEDLE ROLLER :- 13 X 19 X 12	1	
21	LBB00007	SCREW PAN CROSS M6X1	1	
22	JG541045	PLATE STOPPER	1	
23	DP101191	BOLT (M8 X 1.25 X LENGTH = 15.5)	1	
24	JG571014	OIL FILTER	1	



Sr. No.	Part No.	Description	QTY.	Remarks
25	JG571016	RING O	1	
26	JL571001	CAP OIL FILTER	1	
26	56JL1X4X	CAP OIL FILTER JL571001 SATIN BLACK	1	
27	LAE00055	BOLT FLANGE-M6X1XL16XCL8.8XBLACK	2	
28	JL601010	WATER SEAL_DOUBLE LIP	1	

Pulsar NS 200 (Peru)


11. Crankcase LH



Sr. No.	Part No.	Description	QTY.	Remarks
1	36DT0085	KIT CRANKCASE LH	1	
2	AA101437	SCREW :- PRE-COATED	2	
3	LBB00007	SCREW PAN CROSS M6X1	4	
4	JU541018	BRACKET HARNESS UPPER	1	
5	JG541044	BRACKET HARNESS LOWER_G2	1	
6	KADP0516	BOLT FLANGED M5X0.8	2	
7	JL351808	SWITCH NEUTRAL	1	
8	39104319	SEAL - OIL	1	
9	KEBA3715	CIRCLIP INTERNAL	1	
10	JY541058	OIL SEAL OUTPUT SHAFT	1	
11	59200006	BEARING - BALL	1	
12	JG541015	BEARING NEEDLE	1	

Pulsar NS 200 (Peru)


11. Crankcase LH



Sr. No.	Part No.	Description	QTY.	Remarks
13	39256220	BEARING - NEEDLE ROLLER :- 13 X 19 X 12	1	
14	JY571030	MESH STRAINER ASSLY	1	
15	JA541048	STRAINER CAP WITH O-RING	1	
16	JG541041	GASKET CRANKCASE	1	
17	LJA00004	STRAINER O RING	1	
18	JG541058	CHAIN GUARD	1	
19	BF561020	BEARING PLAIN	1	
20	KAEQ0640	BOLT FLANGE SMALL-M6X1XL40XDACRO	10	
21	LAD00081	BOLT FLANGED M6X1X60L-PRECOATED	4	
22	59210023	RING - O	1	

Pulsar NS 200 (Peru)


12. Balancer Idler Gear / Water Pump



Sr. No.	Part No.	Description	QTY.	Remarks
1	52JL1890	BALANCER ASSEMBLY-JL531205 WITH DOME NUT	1	
2	KPBF6203	BEARING-BALL-C3 CLEARANCE-HN3	2	
3	JL531203	SLEEVE BALANCER DRIVEN	1	
4	JG531229	RING O	1	
5	JG531215	WASHER 2.5MM	1	
6	JG601005	NUT DOMED CAP M6X1	1	
7	JG531207	GEAR BALANCER DRIVEN	1	
8	DS101154	KEY	1	
9	LDB00051	WASHER PLAIN-ID 8.2XOD 26XTHK 3	1	
10	LAC00086	BOLT SOCKET-M8X1XL40	1	
11	36JL0039	KIT WATER PUMP ROTOR & SEAL	1	
12	JL601008	WATER PUMP COVER	1	

Pulsar NS 200 (Peru)


12. Balancer Idler Gear / Water Pump



Sr. No.	Part No.	Description	QTY.	Remarks
13	JG601012	O-RING (WATER PUMP COVER)	1	
14	KAEW0622	BOLT FLANGE SMAL-M6X1XL22XBRIGHT	5	
15	39166511	WASHER - SEAL :- 6	1	
16	39260607	PIN - PARALLEL	2	
17	LAE00017	BOLT FLANGED M6X1	1	

Pulsar NS 200 (Peru)


13. Oil Pump



Sr. No.	Part No.	Description	QTY.	Remarks
1	JU571000	PUMP OIL	1	
2	36JG0004	SHAFT OIL PUMP ASSEMBLY KTM125 EXP	1	
3	JG571018	GEAR OIL PUMP DRIVE	1	
4	KEAB1010	CIRCLIP EXTERNAL	1	
5	39099906	PIN - HOLLOW DOWEL	2	
6	LAE00018	BOLT FLANGED M6X1	3	

Pulsar NS 200 (Peru)


14. Radiator



Sr. No.	Part No.	Description	QTY.	Remarks
1	JL601210	COWL RADIATOR	1	
2	DJ181065	NUT - CLIP :- M6	3	
3	JL181256	GROMMET FOR RADIATOR COWL	3	
4	JL601231	SLEEVE COWL MOUNTING	3	
5	39194404	BOLT - FLANGED	3	
6	JL601000	HOSE THERMOSTAT TO RADIATOR	1	
7	JG601234	CLAMP DIA 23	2	
8	JL601221	CLAMP	1	
9	JL601212	CLAMP RADIATOR DIA 19	1	
10	JL601220	HOSE COOLANT (RAD TO CO PUMP)	1	
11	JL601219	HOSE COOLANT (BLOCK TO CO PUMP)	1	
12	BF601013	CLAMP HOSE	2	

Pulsar NS 200 (Peru)


14. Radiator



Sr. No.	Part No.	Description	QTY.	Remarks
13	JL601228	PIPE COOLANT "T" ASSEMBLY	1	
14	LJA00005	PIPE COOLANT ""T"" O-RING"	1	
15	LAE00041	BOLT FLNG-M6X1XL14XDACROXPRECOAT	2	
16	JL601234	RADIATOR CORE	1	
17	JG601235	PRESSURE CAP RADIATOR	1	
18	JY601238	BRACKET FAN ASSLY A	1	
19	JY601239	BRACKET FAN ASSLY B	1	
20	JY601240	BRACKET FAN ASSLY C	1	
21	JP601235	FAN RADIATOR	1	
22	JY601241	FLANGE NUT	3	
23	LCL00002	NUT HEX FLANGED M6X1	4	
24	KDDB0612	WASHER SPRING THIN	4	

Pulsar NS 200 (Peru)


14. Radiator



Sr. No.	Part No.	Description	QTY.	Remarks
25	39270411	WASHER (SPRING STEEL)	4	
26	JL601216	RUBBER DAMPER RADIATOR MOUNTING	2	
27	JG601211	CAP EXPANSION TANK	1	
28	JG601230	EXPANSION TANK O RING	1	
29	JL601235	TANK ASSEMBLY EXPANSION	1	
30	JL601215	CLAMP -EXPANSION TANK	1	
31	JG171029	SPRING BAND CLAMP 11.5 x 8.4	3	
32	KAED0616	BOLT-FLANGE-KAE ST-D DIA-06 L-16	2	
33	JL601213	HOSE -EXPANSION TANK	1	
34	JG601213	TUBE DRAIN - EXPANSION TANK	1	

Pulsar NS 200 (Peru)


15. Cover Clutch



Sr. No.	Part No.	Description	QTY.	Remarks
1	52JL0892	SF FOR ASSLY CLUTCH COVER JL541233	1	
1	36JL0227	KIT ASSLY CL COVER SATIN BLACK	1	
2	39199020	BEARING - NEEDLE	1	
3	LDB00020	WASHER 12.5X24X0.8T	1	
4	JG551017	SPRING (LEVER CLUTCH)	1	
5	DT541019	SHAFT ASSEMBLY CLUTCH	1	
6	JU551401	ROD PUSH_G2 (FINAL)	1	
7	JG541230	CAP OIL FILLING	1	
8	JL541227	WINDOW OIL GUAGE	1	
9	DS101215	CLIP - WIRE	1	
10	39104119	SEAL - OIL	1	
11	39099906	PIN - HOLLOW DOWEL	2	

Pulsar NS 200 (Peru)


15. Cover Clutch



Sr. No.	Part No.	Description	QTY.	Remarks
12	JL541277	GASKET COVER CLUTCH	1	
13	DT541018	BRACKET CLUTCH CABLE	1	
14	KAEQ0630	BOLT FLANGE SMALL-M6X1XL30XDACRO	11	
15	39104619	SEAL - OIL	1	
16	JG541231	PLATE -POSITION	1	
17	AA101437	SCREW :- PRE-COATED	2	
18	JL541222	DECAL TRIPLE SPARK	1	
19	JL541218	JET OIL COVER CLUTCH	1	
20	JL541230	DAMPER CLUTCH COVER	1	
21	JL541231	PLATE DAMPER CLUTCH COVER	1	
22	DH101388	PRECOATED FLANGED BOLT M5X10 - 39220804	5	
23	KJAA1424	O RING	1	

Pulsar NS 200 (Peru)


16. Cover Magneto



Sr. No.	Part No.	Description	QTY.	Remarks
1	36JL0230	ASSLY MAG COVER SATIN BLACK	1	
2	JL541245	CAP TDC FINDER	1	
3	30101195	RING - O	1	
4	39099906	PIN - HOLLOW DOWEL	2	
5	JG541211	GASKET COVER MAGNETO	1	
6	KAEQ0630	BOLT FLANGE SMALL-M6X1XL30XDACRO	9	
7	JL541203	COVER LH RR	1	
8	KAEQ0645	BOLT FLANGE SMALL-M6X1XL45XDACRO	1	
9	JF233036	LABEL GEAR SHIFT 6 SPEED	1	
10	JF233310	DECAL COVER MAGNETO	1	
11	DT541210	JET OIL STATOR	1	

Pulsar NS 200 (Peru)


17. Clutch Assembly



Sr. No.	Part No.	Description	QTY.	Remarks
1	DT551409	CLUTCH ASSEMBLY COMPLETE	1	
2	DT551412	COLLAR	1	
3	36DT0055	KIT CL HOUSING & PRIMARY GEAR	1	
4	JG551428	WASHER CLUTCH_G2	1	
5	DT551402	PLATE CLUTCH PRESSURE	1	
6	36JU0002	SET FRIC PLATES KTM 200	1	
7	DT551408	CLUTCH PLATE	5	
8	JG551443	CLUTCH HOLDER	1	
9	DT551401	CENTER CLUTCH	1	
10	DT551403	SPRING CLUTCH	4	
11	JG551451	BOLT SH 6*22	4	
12	JL551407	SPRING BELLIVILLE	1	

Pulsar NS 200 (Peru)


17. Clutch Assembly



Sr. No.	Part No.	Description	QTY.	Remarks
13	DH101648	NUT CLUTCH CENTER LOCK PRECOATED	1	
14	JG551423	CLUTCH LIFTER BEARING	1	

Pulsar NS 200 (Peru)


18. Throttle Body



Sr. No.	Part No.	Description	QTY.	Remarks
1	JL611204	BODY THROTTLE ASSEMBLY	1	
2	JG611007	FUEL INJECTOR	1	
3	JL611001	CAP INJECTOR-CONNECTOR QUICK	1	
4	JG581424	FIXING SCREW	5	
5	JG611206	MOTOR STEPPER (IACV)	1	
6	JG351805	SENSOR TMAP	1	
7	JG581437	FIXING SCREW	1	
8	DT351803	SENSOR THROTTLE POSITION	1	
9	DS161156	PLUG - SEAT LOCK CABLE	1	
10	JG611006	CLIP INJECTOR CLIP	1	
11	JG581419	BRACKET THROTTLE CABLE	1	


Pulsar NS 200 (Peru)

19. Air Cleaner Complete



Sr. No.	Part No.	Description	QTY.	Remarks
1	DT581064	ASSEMBLY AIR FILTER	1	
2	KBUA0630	SCREW TRUSS	4	
3	DT581062	FILTER ELEMENT	1	
4	DT581028	SEAL TOP COVER	2	
5	DT581048	BREATHER TUBE ASSEMBLY	1	
6	DT581049	BREATHER TUBE	1	
7	JY581028	CLAMP	2	
8	KADA0630	BOLT FLANGED M6X1	1	
9	JL581055	TUBE DRAIN	1	
10	DG121002	CLAMP	1	
11	JG581056	CLAMP (BREATHER TUBE)	1	
12	DS121126	PLUG	1	


19. Air Cleaner Complete



Sr. No.	Part No.	Description	QTY.	Remarks
13	JU581006	CLAMP CONNECTING TUBE	2	
14	KADD0610	BOLT FLANGED M6X1	1	

Pulsar NS 200 (Peru)


20. Silencer Assembly



Sr. No.	Part No.	Description	QTY.	Remarks
1	LCG00006	NUT HEX FLANGED M8*1.25	2	
2	JP591106	GASKET EXHAUST	1	
3	JL591412	PIPE ASSEMBLY A	1	
4	JG591039	GASKET MUFFLER PIPE-A	1	
5	JG591038	BAND CLIP	1	
6	JL591342	ASSEMBLY MUFFLER	1	
7	JL591148	BOLT HEXAGONAL FLANGE	2	
8	KADA0630	BOLT FLANGED M6X1	2	
9	JL591165	DAMPER SILENCER MOUNTING LOWER	4	
10	JL591156	SLEEVE TOP	4	
11	JL591157	SLEEVE BOTTOM	2	
12	DH101607	SCREW - TRUSS	2	

Pulsar NS 200 (Peru)


20. Silencer Assembly



Sr. No.	Part No.	Description	QTY.	Remarks
13	JL591392	SHIELD MUFFLER	1	
14	JB591098	SENSOR OXYGEN	1	

Pulsar NS 200 (Peru)


21. Starter Assembly




Sr. No.	Part No.	Description	QTY.	Remarks
1	JL351600	MOTOR STARTER	1	
2	JG621413	GEAR ASSEMBLY STARTER COUNTER II	1	
3	JG621412	GEAR STARTER COUNTER 1	1	
4	JG531041	BALANCER DRIVE GEAR	1	
5	LDH00002	WASHER CONICAL	1	
6	JG531040	NUT M28X1.5	1	
7	JG621417	ASSEMBLY GEAR STARTER CLUTCH	1	
8	LDB00010	WASHER PLAIN-ID 10.3XOD29XT3.2XBR	1	
9	52JY0185	BOLT FLANGE PRECOATED M10X1.25XL50	1	
10	JG351019	BODY STARTER CLUTCH	1	
11	JY551402	CLUTCH ONE WAY ASSLY	1	
12	LDF00001	WASHER TOOTHED-ID 6.4XOD11XT 0.7	4	

Pulsar NS 200 (Peru)


21. Starter Assembly




Sr. No.	Part No.	Description	QTY.	Remarks
13	DH101389	PRECOATED PAN SCREW M6 X 20 - 39119704	4	
14	JA351627	O-RING SPIGOT	1	
15	JG541043	RETAINER GEAR STARTER	1	
16	LAE00042	BOLT FLANGED-M6X1	1	
17	KADQ0625	BOLT FLANGED M6X1	2	




Sr. No.	Part No.	Description	QTY.	Remarks
1	JU351004	ROTOR ASSEMBLY	1	
2	JL351059	STATOR ASSEMBLY	1	
3	DK101284	HEX SOCKET HEAD SCREW(M5X0.8X35)	3	
4	KADD0508	BOLT FLANGED M5X0.8	2	
5	JG541223	BRACKET HARNESS	1	
6	KADD0620	BOLT FLANGED M6X1	4	
7	JE351256	COIL HT WITH CABLE-RH	1	
8	DK111011	CAP SPARK PLUG	1	
9	DH111013	GROMMET - SPARK PLUG	2	
10	JL351218	PLUG SPARK	1	
11	JL351252	HT COIL 2	1	
12	DD111012	GROMMET FOR H. T. CABLE	3	




Sr. No.	Part No.	Description	QTY.	Remarks
13	JD351207	SPARK PLUG CAP	1	
14	AN111015	SPARK PLUG CAP	1	
15	DH111016	GROMMET - SLEEVE :- SPARK PLUG	1	
16	DD111011	GROMMET - SPARK PLUG CAP	1	
17	DK111028	SPARK PLUG RG6HCC	2	




Sr. No.	Part No.	Description	QTY.	Remarks
1	JL191001	SEAT ASSEMBLY FRONT	1	
2	JL191017	SEAT DAMPER FRONT	6	
3	DK211007	DAMPER SEAT FRONT	1	
4	JG191008	COLLAR	2	
5	FD211006	GROMMET - SEAT	2	
6	DS161287	FLANGE BOLT - M6	2	
7	JL191004	SEAT ASSEMBLY PILLION	1	
8	JD191006	DAMPER ROUND	2	
9	DT232605	LATCH ASSEMBLY SEAT	1	
10	JG232606	SEAT LOCK CABLE	1	
11	KADD0622	BOLT FLANGED M6X1	2	
12	JL232604	COVER LATCH SEAT	1	



Sr. No.	Part No.	Description	QTY.	Remarks
1	56JL0601	ENG STAY LH WITH BLACK COLOR	1	
2	56JL0701	ENG STAY RH WITH BLACK COLOR	1	
3	LAE00060	BOLT FLANGE-M8X1.25XL23XCL8.8XBR	4	
4	LAJ00018	BOLT STUD-M10X1.25XL 144XBRIGHT	1	
5	JA113403	FLANGED BOLT M10X110	2	
6	KCGD1010	NUT HEX FLANGED	2	
7	JL111092	BRACKET RADIATOR LOWER LH	1	
8	JL111093	BRACKET RADIATOR LOWER MTG RH	1	
9	KAED0612	BOLT-FLANGE-KAE ST-D DIA-06 L-12	4	




Sr. No.	Part No.	Description	QTY.	Remarks
1	JL111246	FRAME ASSEMBLY	1	
2	JL111103	CAP TUBE END	2	
3	JL111078	BRACKET HORN	1	
4	36DK0159	KIT ST. CONE WITH GREASE	1	
5	JG581014	SILENT BLOCK(M6)	2	
6	KADF0608	BOLT FLANGED M6X1	2	
7	DK181075	NUT STEERING	1	
8	DK181076	CUP STEERING	1	
9	JL113809	GROMMET AIR FILTER RESTING	1	
10	DT181323	PLUG 2	1	
11	AA141067	CLIP SWIVEL SPACER	1	
12	KAEA0610	BOLT-FLANGE-KAE ST-A DIA-06 L-10	1	




Sr. No.	Part No.	Description	QTY.	Remarks
13	JF113859	BRACKET VALVE PURGE-RELAY INTERLOCK	1	
14	DS161166	TAPE - II :- FRAME	2	
15	JL113841	CLAMP TIE CABLE	10	
16	DS211004	DAMPER - SEAT :- I	2	
17	DK181050	CAGE BEARING STEERING TOP	1	
18	DK181051	CAGE BEARING STEERING BOTTOM	1	
19	DT111106	FRAME RUBER PAD LH	1	
20	DT111107	FRAME RUBER PAD RH	1	
21	JG113841	TAPE ANTIABRASIVE	1	

Pulsar NS 200 (Peru)

26. Swing Arm / Rear Shock Absorber




Sr. No.	Part No.	Description	QTY.	Remarks
1	JL122037	SHOCKABSORBER REAR	1	
2	LAC00019	BOLT SOCKET M10X1.25	2	
3	DT122029	ARM ASSEMBLY SWING	1	
4	DG171016	SLEEVE	2	
5	DG171018	BEARING - NEEDLE	2	
6	DG171019	SEAL - OIL	4	
7	JL122002	CAP SWING ARM TUBE	2	
8	JL122001	ADJUSTER CHAIN LH	1	
9	JL122009	ADJUSTER CHAIN RH	1	
10	JL122003	SLIDER CHAIN	1	
11	39045411	WASHER - PLAIN	2	
12	KBRB3513	SCREW TAPPING PAN CROSS	2	



Sr. No.	Part No.	Description	QTY.	Remarks
13	JL122004	SPACER CHAIN ADJUSTER	2	
14	JL122008	SPACER	2	
15	JL181224	GROMMET I	1	
16	JL181225	GROMMET II	1	
17	JL122026	SHAFT SWING ARM ASSEMBLY	1	
18	DT113848	CAP SWING ARM PIVOT	2	
19	39105315	NUT - HEXAGON WITH FLANGE :- M14	1	
20	JG113841	TAPE ANTIABRASIVE	1	

Pulsar NS 200 (Peru)


27. Pillion Foot Rest / Holder



Sr. No.	Part No.	Description	QTY.	Remarks
1	56JL5F4X	STEP HOLDER RH JL113060 SATIN BLACK	1	
2	56JF3T4X	STEP RIDER RH JF113006 SATIN BLACK	1	
3	JL113012	SPRING TORSION	2	
4	JL113033	BRACKET REAR BRAKE SWITCH	1	
5	KADD0610	BOLT FLANGED M6X1	1	
6	LAC00045	BOLT SOCKET-M8X1.25XL20XPRE-COAT	8	
7	56JL3X4X	STEP HOLDER LH (JL113057) SATIN BLACK	1	
8	56JL3S4X	STEP RIDER LH JL113009 SATIN BLACK	1	
9	36JL0041	KIT MAIN STEP HARDWARE-P200	2	
10	LDA00013	WASHER PLAIN	1	
11	36JL0240	KIT PILLION HARDWARE-P200	2	
12	56JL4J4X	STEP HOLDER PILLON LH JL113013 SATIN BLK	1	

Pulsar NS 200 (Peru)


27. Pillion Foot Rest / Holder



Sr. No.	Part No.	Description	QTY.	Remarks
13	JF113007	DAMPER FOOTREST (K11)	2	
14	56JL184X	STEP PILLION LH JL113014 SATIN BLACK	1	
15	56JL194X	STEP PILLION RH JL113016 SATIN BLACK	1	
16	56JL4K4X	STEP HOLDER PILLON RH JL113015 SATIN BLK	1	
17	LDB00018	WASHER -PLAIN	3	
18	DJ101305	BOLT FLANGE	3	
19	JL113038	STEP BOLT-SPL	1	
20	LCL00001	NUT HEX FLANGE-M10X1.25XHT.10XBR	1	
21	JZ113061	RUBBER PAD STEP	2	
22	JL113036	DAMPER STEP PILLION	2	
23	JF113008	LOCK PLATE FOOTREST (K11)	1	
24	DT113015	PLATE LOCK RH	1	

Pulsar NS 200 (Peru)


27. Pillion Foot Rest / Holder



Sr. No.	Part No.	Description	QTY.	Remarks
25	KDAA0816	WASHER-KDA-OD/ID/THK-16/8.5/1.2	1	
26	JL113006	RUBBER MAIN STEP	2	
27	JL113035	BOLT M6X1	2	
28	JL113037	PIN CLEVIS DIA 8	2	
29	KHAA2520	PIN COTTER	6	

Pulsar NS 200 (Peru)


28. Mudguard - Front & Rear



Sr. No.	Part No.	Description	QTY.	Remarks
1	KACA0520	BOLT SOCKET M5X0.8	2	
2	DT181434	CUP WASHER FRONT FENDER MTG	2	
3	DT181435	GROMMET FRONT FENDER - K8	2	
4	JL181468	COLLAR	2	
5	KADD0614	BOLT FLANGED M6X1	2	
6	JG113407	BOLT FLANGED M8X1.25	4	
7	DJ161091	GROMMET - FRONT FENDER	4	
8	JL181464	BRACE ASSEMBLY FENDER	1	
9	DT181433	PLUG FRONT FENDER REAR	1	
10	JL181405	MUDFLAP -FRONT	1	
11	KBBC0512	SCREW PAN CROSS	3	
12	KDAA0510	WASHER PLAIN SMALL	6	

Pulsar NS 200 (Peru)


28. Mudguard - Front & Rear



Sr. No.	Part No.	Description	QTY.	Remarks
13	39032615	NUT - NYLOC :- M5 X 0.8	3	
14	JL131945	BRACKET CLAMP HOSE	1	
15	DT131875	CLAMP	1	
16	KAEA0622	BOLT FLANGED	1	
17	JL181209	FENDER REAR FRONT	1	
18	JL181325	PLUG	1	
19	JL181221	FOAM-REAR FENDER FRONT	1	
20	LDB00023	WASHER PLAIN	2	

Pulsar NS 200 (Peru)


29. Stand Assembly



Sr. No.	Part No.	Description	QTY.	Remarks
1	36JL0025	KIT CENTER STAND-P200 NS	1	
2	DG161124	DAMPER	1	
3	JL113210	BUSH STAND MAIN	2	
4	LAD00134	BOLT FLANGE-M8X1.25XL60XCL12.9XDC	1	
5	KADF0812	BOLT FLANGED M8X1.25	1	
6	LAD00135	BOLT FLANGE-M8X1.25XL70XCL12.9XDC	1	
7	JL113207	SPRING TENSION	1	
8	JL113212	COVER SPRING MAIN STAND	1	
9	JL113201	STAND SIDE	1	
10	JF401405	SIDE STAND SWITCH - K10	1	
11	LCH00001	NUT NYLOC-M10X1.25XHT.11XCL6XBRT	1	
12	DF161102	BOLT FOR SIDE STAND MOUNTING	1	

Pulsar NS 200 (Peru)

29. Stand Assembly




Sr. No.	Part No.	Description	QTY.	Remarks
13	KADS0516	BOLT FLANGED M5X0.8	1	
14	JZ403601	HOLDER MAGNET	1	
15	JL113209	SPRING TENSION	1	
16	DH161146	COVER - SPRING :- SIDE STAND	1	
17	JL113202	BRACKET STAND SIDE_OKAYFERN	1	
17	52JL0072	Bkt Side Stand w/o Powder Coating AFT ED	1	
18	JL113818	COVER SWITCH STAND SIDE	1	
19	JL113206	SPRING MAIN STAND WITH COVER	1	



Sr. No.	Part No.	Description	QTY.	Remarks
1	DT131018	TYRE 100/80-17	1	
2	DK151026	VALVE TUBELESS TYRE	2	
3	JL131004	WHEEL FRONT MT 2.50X17	1	
4	JL131209	WHEEL 3.50X17	1	
5	DT131222	TYRE 130/70-17	1	

Pulsar NS 200 (Peru)


31. Front Hub



Sr. No.	Part No.	Description	QTY.	Remarks
1	JL131001	AXLE	1	
2	DT131017	COLLAR ASSEMBLY WHEEL FRONT	1	
3	KPBC6202	BEARING-BALL-C3 CLEARANCE	2	
4	JL131004	WHEEL FRONT MT 2.50X17	1	
5	JG131001	SLEEVE ASSEMBLY	1	
6	DG151005	SEAL - OIL	1	
7	DT131802	DISC -300 MM	1	
8	JU131801	SENSOR DISC FRONT	1	
9	JD131811	SCREW SOCKET STEP M8X1.25	6	
10	JL131000	COLLAR	1	
11	LDB00029	WASHER PLAIN	1	
12	LCJ00002	NUT U M14X1.5	1	

Pulsar NS 200 (Peru)


31. Front Hub



Sr. No.	Part No.	Description	QTY.	Remarks
13	DK201164	SENSOR SPEED WHEEL	1	
14	KADD0614	BOLT FLANGED M6X1	1	
15	DT131878	CLAMP W ABS HOSE-SPEED SENSOR	1	

Pulsar NS 200 (Peru)


32. Front Master Cylinder



Sr. No.	Part No.	Description	QTY.	Remarks
1	JG161010	BRAKE LEVER FRONT	1	
2	DJ191029	BOLT - FR BRAKE LEVR	1	
3	DJ191030	NUT - FR BRAKE LEVER	1	
4	36DH1902	O Ring Kit Master Cyl.Pulsar DTS-I	1	
5	DJ191031	SCREW	2	
6	DE191029	COVER - RESERVOIR	1	
7	DE191028	DIAPHRAGM	1	
8	JF131816	CYLINDER ASSEMBLY MASTER FRONT	1	
9	36DT0036	SWITCH KIT - FR MASTER	1	
10	DE191010	WASHER - COPPER :- KBX	4	
11	DK151069	BOLT -M10X1XL 19XCL 8.8XBRIGHT	4	
12	36JL0190	HOSE KIT-FR MASTER CYL TO ABS	1	


Pulsar NS 200 (Peru)

32. Front Master Cylinder



Sr. No.	Part No.	Description	QTY.	Remarks
13	KADD0830	BOLT FLANGED M8X1.25	2	
14	36DT0034	MJR KIT # FR MASTER CYL (Ø13	1	
15	36JF0081	KIT CLAMP KIT MAST CYL	1	


33. Front Disc Brake



Sr. No.	Part No.	Description	QTY.	Remarks
1	JL131951	CALIPER ASSEMBLY FRONT	1	
2	DE151046	SCREW - BLEEDER :- KBX	1	
3	DE151047	CAP - BLEEDER :- KBX	1	
4	JL131807	BOOT	1	
5	JL131805	PAD	1	
6	YJL04004	MINOR KIT CALIPER FRONT	1	
7	JL131830	MAJOR KIT- CALIPER	1	
8	DH151039	BOLT - FLANGE :- PRE-COATED (M8 X 30) -B	2	

Pulsar NS 200 (Peru)


34. Rear Hub



Sr. No.	Part No.	Description	QTY.	Remarks
1	DK201164	SENSOR SPEED WHEEL	1	
2	KADD0614	BOLT FLANGED M6X1	1	
3	JL131203	AXLE	1	
4	LDB00029	WASHER PLAIN	2	
5	LCL00004	NUT U FLANGE-M8X1.25XHT8.5XBRT	6	
6	JL131211	SPACER	1	
7	DK151012	SEAL_OIL COUPLING 47X28X7	1	
8	KPAC6005	BEARING BALL ORDINARY CLEARANCE	1	
9	JL131225	COUPLING -6 LUG	1	
10	LAA00019	BOLT D-M8X1.25XL50XCL 10.9XBLACK	6	
11	DK151015	SLEEVE	1	
12	JL131232	DAMPER COUPLING	1	

Pulsar NS 200 (Peru)


34. Rear Hub




Sr. No.	Part No.	Description	QTY.	Remarks
13	KPBC6202	BEARING-BALL-C3 CLEARANCE	1	
14	JL131209	WHEEL 3.50X17	1	
15	JL131216	SPACER ASSEMBLY	1	
16	KPBC6302	BEARING-BALL-C3 CLEARANCE	1	
17	30151082	SEAL OIL	2	
18	JL131930	DISC REAR DIA 230MM	1	
19	DH151040	BOLT -SOCKET HEAD:- PRE-COATED (M6 X 20)	6	
20	JU131802	SENSOR DISC REAR	1	
21	JG131220	SCREW PAN CROSS-M6X1XL12XPRECOAT	3	
22	DK151082	SPACER II	1	
23	DK151081	SPACER I	1	
24	LCJ00002	NUT U M14X1.5	1	

Pulsar NS 200 (Peru)


34. Rear Hub



Sr. No.	Part No.	Description	QTY.	Remarks
25	36JL0184	KIT CHAIN SPROCKET EUIV	1	




Sr. No.	Part No.	Description	QTY.	Remarks
1	JF131858	CALIPER ASSEMBLY REAR	1	
2	DT131866	REAR MASTER CYLINDER ASSEMBLY	1	
3	JL131907	BRAKE HOSE REAR	1	
4	DK151069	BOLT -M10X1XL 19XCL 8.8XBRIGHT	2	
5	JG131821	RESERVOIR REAR BRAKE	1	
6	JL131220	HOSE -RESEVOIR	1	
7	JL131878	BRACKET -RESERVOIR CAP	1	
8	DE191010	WASHER - COPPER :- KBX	4	
9	DE151047	CAP - BLEEDER :- KBX	1	
10	DE151046	SCREW - BLEEDER :- KBX	1	
11	YJL04005	MAJOR KIT CALIPER ASSLY REAR	1	
12	YJL04006	MINOR KIT CALIPER ASSLY REAR	1	




Sr. No.	Part No.	Description	QTY.	Remarks
13	DK151085	PAD BRAKE REAR SET	1	
14	LHA00001	PIN	1	
15	KDAA0611	WASHER PLAIN SMALL	1	
16	KHAA2015	PIN SNAP	1	
17	36DT0039	MJR KIT - REAR M/ CYL-(Ø14)	1	
18	36DT0040	MINOR KIT - REAR M/ CYL-(Ø14)	1	
19	DK151045	REAR MASTER CYLINDER CAP	1	
20	36JG0083	KIT BRAKE FLUID RESERVOIR	1	
21	KADT0612	BOLT FLANGED M6X1	1	
22	JL131841	BRACKET RESERVOIR	1	
23	KADD0614	BOLT FLANGED M6X1	1	
24	JL131877	CLAMP HOSE RESERVOIR	2	

Pulsar NS 200 (Peru)

36. Rear Brake Pedal




Sr. No.	Part No.	Description	QTY.	Remarks
1	JL161017	PEDAL BRAKE	1	
2	KADD0610	BOLT FLANGED M6X1	1	
3	JL131928	SHAFT ASSEMBLY BRAKE	1	
4	DH191013	SPACER FOR BRAKE SHAFT ASSEMBLY	1	
5	JL401406	BRAKE SWITCH-REAR	1	
6	JA621206	BOLT SPECIAL (M8*30)	1	
7	JL113033	BRACKET REAR BRAKE SWITCH	1	
8	JL161006	SPRING REAR BRAKE SWITCH	1	
9	DH191006	SPRING - BRAKE PEDAL	1	
10	KJAA1424	O RING	2	



Sr. No.	Part No.	Description	QTY.	Remarks
1	JL131940	UNIT ABS WET	1	
2	36JL0190	HOSE KIT-FR MASTER CYL TO ABS	1	
3	36JL0191	HOSE KIT -FR CALIPER TO ABS HOSE	1	
4	JF113854	BRACKET ABS	1	
5	LAE00021	BOLT FLANGED M6X1	3	
6	JB113007	PLAIN WASHER	1	
7	KAED0608	BOLT-FLANGED-SMALL	3	
8	DT131875	CLAMP	4	
9	KAEA0622	BOLT FLANGED	1	
10	DE191010	WASHER - COPPER :- KBX	8	
11	DK151069	BOLT -M10X1XL 19XCL 8.8XBRIGHT	4	

Pulsar NS 200 (Peru)


38. Handle Bar Assembly



Sr. No.	Part No.	Description	QTY.	Remarks
1	JL151021	TUBE ASSEMBLY HANDLEBAR LH	1	
2	56JL315X	HANDLE HOLDER LH STOIC BLACK	1	
3	KDBA0818	WASHER PLAIN	2	
4	LAC00020	BOLT SOCKET M8X1.25	2	
5	JL151028	PLUG HANDLE HOLDER	2	
6	56JL325X	HANDLE HOLDER RH STOIC BLACK	1	
7	JL151034	TUBE ASSEMBLY HANDLEBAR RH	1	
8	LAC00059	BOLT SOCKET M8X1.25	4	
9	JL151035	HANDLEBAR WEIGHT	2	
10	KACG0645	BOLT SOCKET M6X1	2	
11	JL161016	ASSEMBLY LEVER-HOLDER LH	1	
12	JG161008	LEVER LH	1	

Pulsar NS 200 (Peru)


38. Handle Bar Assembly



Sr. No.	Part No.	Description	QTY.	Remarks
13	JG401416	SWITCH CLUTCH (VB)	1	
14	KADD0625	BOLT FLANGED M6X1	1	
15	JL161003	HANDLE GRIP LH	1	
16	DT161005	GRIP ASSEMBLY RH	1	
17	JG151022	PIPE THROTTLE	1	
18	JL151023	LOCK SET 3 IN 1	1	
19	JL401403	SWITCH IGNITION	1	
20	JF401416	SWITCH CONTROL LH	1	
21	JF401417	SWITCH CONTROL RH	1	
22	JL231601	MIRROR ASSY RH	1	
23	JL231600	MIRROR ASSY LH	1	
24	LBU00012	SCREW PAN CROSS M3X0.5	2	

Pulsar NS 200 (Peru)


38. Handle Bar Assembly



Sr. No.	Part No.	Description	QTY.	Remarks
25	DJ201109	SWITCH BRAKE	1	
26	DS191052	LEVER BOOT LH FOR CLUTCH SWITCH	1	
27	JL161014	HOLDER LEVER LH	1	
28	36DU1901	CABLE ADJ.KIT - CT 100	1	
29	JL151038	O RING	4	

Pulsar NS 200 (Peru)


39. Front Fork



Sr. No.	Part No.	Description	QTY.	Remarks
1	JL121005	FORK ASSLY ABS -K16A	1	
2	DT121052	TUBE OUTER LH PC	1	
3	DT121053	TUBE OUTER RH PC	1	
4	DK181006	SOCKET HEADED BOLT - M10 X1.5X35	2	
5	DK181007	COPPER WASHER	2	
6	DK181021	INNER DUST SEAL	2	
7	DK181018	WASHER SEAL	2	
8	DJ171039	OIL SEAL	2	
9	DK181017	GUIDE BUSH	2	
10	DK181020	OIL SEAL STOPPER	2	
11	JL121008	FORK PIPE INNER -K16A ABS	2	
12	DK181009	CAP OIL LOCK	2	

Pulsar NS 200 (Peru)


39. Front Fork




Sr. No.	Part No.	Description	QTY.	Remarks
13	DK181010	SEAT PIPE	2	
14	DK181012	PISTON RING	2	
15	JL121001	MAIN SPRING	2	
16	DK181022	FORK BOLT	2	
17	DK181023	O' RING	2	
18	56JL335X	UPPER BRACKET STOIC BLACK	1	
19	JL181235	FRAME LAMP HEAD	1	
20	JC181023	COVER CUSHION	4	
21	JC181022	COVER TRAIL 'B'	4	
22	JL151037	UNDER BKT ASSY COMPLETE	1	
23	DK181025	SPRING WASHER	2	
24	DK181028	BOLT M10X1.5	2	

Pulsar NS 200 (Peru)


39. Front Fork




Sr. No.	Part No.	Description	QTY.	Remarks
25	KACF0830	BOLT SOCKET M8X1.25	2	
26	JY151011	BOLT FLANGED-M16X1.5XL33XPRECOAT	1	
27	DK181013	REBOUND SPRING	2	
28	DG181003	WASHER	1	
29	JL121007	ASSEMBLY LEG LH-K16A ABS	1	
30	JL121006	ASSEMBLY LEG RH-K16A ABS	1	
31	JH401031	REFLECTOR REFLEX SIDE	2	
32	DK181011	SLIDE BUSH	2	




Sr. No.	Part No.	Description	QTY.	Remarks
1	JL181019	SHROUD ASSEMBLY RH	1	
2	KBUA0512	SCREW TRUSS	4	
3	JW181236	CLIP NUT M5	4	
4	KBUA0612	Mushroom Head screw - M6-L12	4	
5	KAED0616	BOLT-FLANGE-KAE ST-D DIA-06 L-16	2	
6	JL181232	SHROUD MTG BKT RH	1	
7	39214124	WASHER NYLON 5.3X11.5X1.5	2	
8	DJ181065	NUT - CLIP :- M6	4	
9	JL181017	SHROUD ASSEMBLY LH	1	
10	JB181223	BEADING SPEEDO FLAP	2	
11	KBRA4813	SCREW TAPPING PAN CROSS	2	
12	KDBA0512	WASHER PLAIN	2	




Sr. No.	Part No.	Description	QTY.	Remarks
13	PD591100	WASHER SHIELD	2	




Sr. No.	Part No.	Description	QTY.	Remarks
1	52JL2355	K4 FUEL TANK ASSLY JL171116 ASIAN PUMP	1	
2	JL151023	LOCK SET 3 IN 1	1	
3	KACD0516	BOLT SOCKET M5X0.8	6	
4	JL171049	DAMPER RING	1	
5	36JL0012	KIT TANK DAMPER-P200	1	
6	AA201375	PUMP FUEL	1	
7	JR171820	PLATE PRESSURE	1	
8	KACG0610	BOLT SOCKET M6X1	6	
9	JL171063	PIPE DRAIN	1	
10	JL171073	DAMPER TANK CVR RESTIG RR	1	
11	JH171803	GASKET FUEL PUMP MTG	1	
12	JL402602	FUEL LEVEL SENSOR(JNS)	1	




Sr. No.	Part No.	Description	QTY.	Remarks
13	LAD00151	BOLT FLANGED M8X1.25	3	
14	DT171075	COLLAR	1	
15	JL171018	GROMMET TANK MTG FRONT	1	
16	JL171019	COLLAR	2	
17	JL171020	GROMMET TANK MTG REAR	2	
18	JH171017	O RING FUEL GAUGE	1	




Sr. No.	Part No.	Description	QTY.	Remarks
1	JL171057	DAMPER -TANK SIDECOVER	4	
2	JL171022	BRACKET SIDE COVER MTG LH	1	
3	KADA0516	BOLT FLANGED M5X0.8	4	
4	DJ161229	CLIP NUT M5	16	
5	JL171024	DAMPER STRUCTURE MTG	6	
6	JL171048	COVER ASSLY TANK MIDDLE	1	
7	KBRA4213	SCREW TAPPING PAN CROSS	16	
8	KADD0514	BOLT FLANGED M5X0.8	2	
9	31161078	WASHER	2	
10	LAC00022	BOLT SOCKET-SPECIAL HEAD	4	
11	39214124	WASHER NYLON 5.3X11.5X1.5	8	
12	DH161158	GROMMET - SIDE COVER	2	



Sr. No.	Part No.	Description	QTY.	Remarks
13	KBUA0612	Mushroom Head screw - M6-L12	5	
14	59020001	SCREW SELF TAPPING 3.5X9.5	10	
15	JL171062	GRILL -TANK SIDE COVER RH	1	
16	JL171061	GRILL-TANK SIDE COVER LH	1	
17	KADD0614	BOLT FLANGED M6X1	2	
18	LAC00063	BOLT SOCKET-M6X1XL22XCL 8.8XBRT	2	
19	LDA00018	WASHER 6.2X20X1.5 Black	4	
20	JL181336	FOAM	8	
21	DJ201173	GROMMET FOR CABLES- REAR FENDER	2	
22	JL181220	GROMMET -2 SEAT COWL	2	
23	JL181214	SEAT COWL CENTRAL INNER	1	
24	JL171099	BRACKET SIDE COVER MTG RH (K14	1	




Sr. No.	Part No.	Description	QTY.	Remarks
25	JF113843	BRACKET HARNESS HOLDING	1	
26	36JL0031	KIT Tank Cover Mtg Hardware	1	
27	DS141012	GROMMET - SIDE COVER :- FRONT	2	
28	KADD0616	BOLT FLANGED M6X1	2	
29	JL181288	SCREW STEPPED M6 X 14	2	
30	JL191008	SEAT TAPE LH	1	
31	JL191009	SEAT TAPE RH	1	
32	JL171078	PAD TANK COVER	1	
33	JL113832	BRACKET COVER TANK	1	
34	JD171018	DUAL LOCK TAPE 3M - SIZE 10X20	1	N.I.
35	JL171823	ADD-ON BKT LH TANK TOP COVER (K16)	1	
36	JL171824	ADD-ON BKT RH TANK TOP COVER (K16)	1	



Sr. No.	Part No.	Description	QTY.	Remarks
37	JL171040	COLLAR	2	
38	LAC00034	BOLT M6 X 20	2	

Pulsar NS 200 (Peru)


43. Meter Assembly




Sr. No.	Part No.	Description	QTY.	Remarks
1	JL402414	SPEEDOMETER	1	
2	JG181238	GROMMET DASHBOARD	3	
3	LDB00007	WASHER PLAIN	3	
4	KCAA0504	X THICK (Nut)	3	
5	KACH0514	BOLT SOCKET M5X0.8	4	
6	JL181241	FLAP ASSEMBLY SPEEDOMETER	1	
7	JB181223	BEADING SPEEDO FLAP	2	
8	KACH0835	BOLT SOCKET M8X1.25	4	
9	JF181349	FOAM	6	

Pulsar NS 200 (Peru)


44. Control Cables




Sr. No.	Part No.	Description	QTY.	Remarks
1	JL161205	THROTLE CABLE (K14)	1	
2	JL161200	CABLE CLUTCH	1	




Sr. No.	Part No.	Description	QTY.	Remarks
1	JL181205	COVER ASSLY CHAIN	1	
2	JG122028	EXTRUDED WASHER	2	
3	KAED0608	BOLT-FLANGED-SMALL	2	
4	DT181416	ASSEMBLY REAR HUGGER COMP(K8)	1	
5	DT181000	TUBE HUGGER	1	
6	DT181415	COVER TUBE HUGGER	1	
7	JL181408	COVER 2-HUGGER REAR	1	
8	KBUF0408	SCREW TRUSS-M4X0.7XL 8XBLACK	6	
9	LAC00037	SCREW BUTN HD-M6X1XL8XBLXPRECOAT	3	
10	KDDF0815	WASHER SPRING-ID8.1XOD14.8XT2XBL	2	
11	LAC00128	BOLT SOKET-M8X1.25XL42XBLXPRECOT	2	
12	JL181410	COLLAR	2	




Sr. No.	Part No.	Description	QTY.	Remarks
13	JL181253	CHAIN COVER SIDE RH	1	
14	LBU00078	SCREW BUTTON HEAD-M6X1XL 17XBLK	2	
15	DS161187	COLLAR FOR MUDCOVER	4	
16	JL181307	BRACKET BELLY PAN	1	
17	JY181255	WASHER END CAP	8	
18	LBU00077	SCREW TRUSS-M6X1XL 20XCL 4.8XBRT	4	
19	LAD00205	BOLT FLANGED M6X1	1	
20	KADD0612	BOLT FLANGED M6X1	2	
21	KACH0616	BOLT SOCKET M6X1	2	



Sr. No.	Part No.	Description	QTY.	Remarks
1	JL181008	WINDSHIELD ASSEMBLY	1	
2	JG181236	WELL NUT - M5 X 16 LC	2	
3	JG181235	WASHER SPECIAL	2	
4	LBS00002	SCREW CSK-SOCKET HD-M5XL20XBLACK	2	
5	JL181247	GROMMET WIND SCREEN MOUNTING	2	
6	JL181203	FAIRING	1	
7	KDBA0512	WASHER PLAIN	6	
8	LBR00002	SCREW TAPPING PAN DIA 5	6	
9	JL401018	LAMP HEAD ASSEMBLY	1	
10	KADT0614	BOLT FLANGED M6X1	6	
11	JL181245	GROMMET NUMBER PLATE MOUNTING	2	
12	KBUA0516	SCREW TRUSS	2	




Sr. No.	Part No.	Description	QTY.	Remarks
13	39214124	WASHER NYLON 5.3X11.5X1.5	2	
14	KBUA0616	SCREW TRUS	1	
15	JL181236	BRACKET LOWER MTG	1	
16	JL181249	DAMPER HEAD LAMP	1	
17	JL181237	BRACKET UPPER MTG	1	
18	JL181235	FRAME LAMP HEAD	1	
19	KACH0835	BOLT SOCKET M8X1.25	4	
20	JL181257	COLLAR	4	
21	DK201044	BULB- 12V 5 WATT FOR PO (WHITE OUTPUT)	2	
22	PD401014	BULB H4 BLUE TINGE - 12V55/60W	1	
23	PA181292	GROMMET FAIRING MTG	4	
24	PA181293	COLLER	4	



Sr. No.	Part No.	Description	QTY.	Remarks
25	KDAA0611	WASHER PLAIN SMALL	3	
26	JL181283	BRACKET WIND SHIELD	1	
27	JL181284	STEP BOLT	2	

Pulsar NS 200 (Peru)


47. Indicator Light Assembly



Sr. No.	Part No.	Description	QTY.	Remarks
1	JL401004	INDICATOR ASSY RR RH	2	
2	JL401006	INDICATOR ASSY FR RH	2	
3	KCGD1010	NUT HEX FLANGED	4	
4	GH201012	LAMP :- 12V - 10W (COLOUR :- AMBER)	4	


Pulsar NS 200 (Peru)

48. Tail Lamp Assembly / Number Plate




Sr. No.	Part No.	Description	QTY.	Remarks
1	KBUA0516	SCREW TRUSS	2	
2	39214124	WASHER NYLON 5.3X11.5X1.5	2	
3	LCA00008	NUT	2	
4	JL232806	PLATE NUMBER-FRONT (BLACK)	1	
5	JZ181320	FOAM NUMBER PLATE FRONT	2	
6	LAC00030	BOLT SOCKET M8X1.25	2	
7	JL232824	BRACKET ASSEMBLY PLATE NUMBER	1	
8	JL401002	LAMP TAIL ASSY	1	
9	KBUA0514	SCREW TRUSS M5	3	
10	DJ161229	CLIP NUT M5	3	
11	LAD00149	BOLT FLANGED M8X1.25	2	
12	56JL6F4X	BRACKET R BLINKER MTG JL113800 SATIN BLK	1	

48. Tail Lamp Assembly / Number Plate




Sr. No.	Part No.	Description	QTY.	Remarks
13	KCGA0606	NUT HEX FLANGED	2	
14	JL113803	BRACKET -REFLECTOR REFLEX MTG	1	
15	JL113811	GROMMET -ILLUMINATION BKT	2	
16	JL113812	COLLAR	2	
17	JL232808	BRACKET -RR NUMBER PLATE MTG	1	
18	DF161252	PLATE - NUMBER :- REAR IN BLACK	1	
19	KADD0610	BOLT FLANGED M6X1	2	
20	KBBA0514	SCREW PAN CROSS	2	
21	JL401016	COVER LAMP	1	
22	JL113810	BRACKET NUMBER PLATE ILLUM	1	
23	JD401007	REAR NUMBER PLATE LAMP	1	
24	JG401036	REFLECTOR REFLEX	1	


48. Tail Lamp Assembly / Number Plate




Sr. No.	Part No.	Description	QTY.	Remarks
25	KCGA0505	NUT HEX FLANGED	1	
26	JD402212	BAND(LENGTH 200MM)	2	




Sr. No.	Part No.	Description	QTY.	Remarks
1	JL402275	HARNESS WIRING	1	
2	JL403000	RELAY INTERLOCK	9	
3	30191048	BAND	1	
4	JG402228	FUSE 10A (BLADE TYPE)	2	
5	DT402226	FUSE 7.5A MINI	5	
6	DT402227	FUSE 5A MINI	2	
7	JY402235	PIGTAIL PH-3 FUEL PUMP	1	
8	DT402223	EARTH CABLE	1	
9	JG401601	HORN	1	
10	KDBC0818	WASHER PLAIN	1	
11	KADF0814	BOLT FLANGED M8X1.25	1	
12	PA402207	CABLE RELAY-MOTOR	1	




Sr. No.	Part No.	Description	QTY.	Remarks
13	DH201124	RELAY STARTER	1	
14	JF181272	BATTERY CASE EPM 44	1	
15	KAEA0622	BOLT FLANGED	3	
16	DS201025	FLASHER - D. C. :- SOLID STATE	1	
17	PA402204	BAND(LENGTH 110MM)	2	
18	JD402212	BAND(LENGTH 200MM)	17	
19	JD402217	BAND(L 150)	7	
20	KACF0612	BOLT SOCKET M6X1	2	
21	JF113842	BRACKET SENSOR ROLL OVER	1	
22	LAC00008	SCREW BUTTON HEAD-M6X1XL20XBLACK	2	
23	JY403604	SENSOR ROLL OVER	1	
24	KCHA0608	NUT NYLOC	2	



Sr. No.	Part No.	Description	QTY.	Remarks
25	JF171064	BAND CABLE	1	
26	JY113864	BRACKET ECU MTG TOP C SAMPLE	1	
26	DT113869	BRACKET ECU	1	
27	JY171007	DAMPER	2	
28	JY113874	DAMPER	1	
29	JY113877	GROMMET	1	
30	JF181282	BRACKET ECU LOWER	1	
31	JY113872	PAD RESTING ECU C SAMPLE LH	1	
32	JY113873	PAD RESTING ECU C SAMPLE RH	1	
33	KCGA0606	NUT HEX FLANGED	4	
34	JP351439	ECU	1	
34	PD351425	ECU EMS	1	



Sr. No.	Part No.	Description	QTY.	Remarks
35	JF181308	RUBBER BATTERY CASE -K10	1	
36	JL113825	BAND BATTERY CASE-VERT ECU	1	
37	DT181022	BAND BATTERY CASE	1	
38	36JU0015	KIT KTM 200 8AH BATTERY+Bottle	1	
39	PD402006	REGULATOR	1	
40	KADa0625	BOLT FLANGED M6X1	2	
41	JP403002	DAMPER RELAY STARTER	1	
42	KADD0616	BOLT FLANGED M6X1	1	
43	JL403201	UNIT TERMINATION	1	
44	DK201188	UNIT TRANSIL	1	
45	JG402230	FUSE 30A (BLADE TYPE)	1	
46	DT113871	DAMPER	1	




Sr. No.	Part No.	Description	QTY.	Remarks
47	DT113870	PAD	1	
48	DT113872	DAMPER	1	

Pulsar NS 200 (Peru)


50. Tool Kit



Sr. No.	Part No.	Description	QTY.	Remarks
1	DJ221019	TOOLKIT	1	
2	JL231003	TOOL KIT-BAND	2	




Sr. No.	Part No.	Description	QTY.	Remarks
1	JL231213	GUARD LEG LH	1	
2	JL231214	GUARD LEG RH	1	
3	JL231404	GRAB HANDLE ASSY LH	1	
4	JL231405	GRAB HANDLE ASSY RH	1	
5	LAC00035	BOLT SOCKET M8X1.25	4	
6	JL231202	GUARD SAREE	1	
7	KACA0618	BOLT SOCKET M6X1	3	
8	LAC00087	BOLT SOCKET-M8X1XL40XPHOSPHATISE	2	
9	KDBA0613	WASHER PLAIN	2	
10	DH161245	NUT - U :- M8 X 1.25	2	
11	LAA00051	BOLT -M8X1.25XL 14XCL 8.8XBLACK	2	
12	JL231209	PLUG SAREE GAURD	3	




Sr. No.	Part No.	Description	QTY.	Remarks
13	KDAA1018	WASHER PLAIN	1	
14	KDDB1018	WASHER SPRING THIN	1	

Pulsar NS 200 (Peru)

52. Painted Parts and Decals




Sr. No.	Part No.	Description	QTY.	Remarks
1	52JL1999	K4 TANK COVER TOP ASSLYPEWTERGREY SA BLK	1	
2	52JL1980	TANK COVER SIDE RH PEWTER GREY+DECAL	1	
3	52JL1979	TANK COVER SIDE LH PEWTER GREY+DECAL	1	
4	52JL1938	SIDE MASK RH SATIN BLACK+DECAL GREY	1	
5	52JL1934	SIDE MASK LH SATIN BLACK+DECAL GREY	1	
6	52JL1984	SEAT COWL ASSY JL181005 PEWTE GREY+DECAL	1	
7	52JL2180	BELLY PAN RH SAT BLK+DEC PEW GREY N C&G	1	
8	52JL2179	BELLY PAN LH SAT BLK+DEC PEW GREY N C&G	1	
9	52JL2018	K4 BS6 ASLY SIDE COVER LH SATIN BLACK+D	1	
10	52JL2019	K4 BS6 COVER SIDE ASSY RHÂ SATIN BLACK+D	1	
11	JL233002	B LOGO DECAL FRONT	1	
12	JF233308	DECAL 3D TANK	2	



Sr. No.	Part No.	Description	QTY.	Remarks
13	JL541222	DECAL TRIPLE SPARK	1	
14	JF233310	DECAL COVER MAGNETO	1	
15	JF233300	DECAL FENDER FRONT LH	1	
15	JF233301	DECAL FENDER FRONT RH	1	
16	JF233288	EMBLEM FUEL INJECTION LH	1	
16	JF233289	EMBLEM FUEL INJECTION RH	1	
17	JL233379	DECAL BELLY PAN PEWTER GREY RH	1	
17	JL233378	DECAL BELLY PAN PEWTER GREY LH	1	
18	36JL0248	KIT TANK COVER TOP DECAL	1	
19	JF233457	DECAL WHEEL FRONT PEWTER GREY LH	1	
19	JF233458	DECAL WHEEL FRONT PEWTER GREY RH	1	
20	36JL0247	KIT FAIRING DECAL	1	

Pulsar NS 200 (Peru)

52. Painted Parts and Decals



Sr. No.	Part No.	Description	QTY.	Remarks
21	36JL0262	KIT SEAT COWL DCL-BLACK	1	
22	36JL0220	KIT DCL TANK SIDE COVER GRAY	1	
23	52JL2012	K4 BS6 ABS FENDER FRONT SATIN BLACK+DEC	1	



Sr. No.	Part No.	Description	QTY.	Remarks
1	52JL2033	K4 BS6 ASSEMBLY TIE ROD(JL561412)WITHNUT	1	N.I.
2	52JL2034	K4BS6 ASSLYLEVER COMPCHANGEGEAR JL561413	1	N.I.
3	56JL335X	UPPER BRACKET STOIC BLACK	1	
4	56JL6F4X	BRACKET R BLINKER MTG JL113800 SATIN BLK	1	
5	52JL0156	ENG STAY ASSLY LH WITH BLACK COLOUR	1	
6	52JL0157	ENG STAY ASSLY RH WITH BLACK COLOUR	1	
7	56JL5F4X	STEP HOLDER RH JL113060 SATIN BLACK	1	
8	56JL244X	SHROUD INNER LH JL181018 SATIN BLACK	1	
9	56JL315X	HANDLE HOLDER LH STOIC BLACK	1	
10	56JL325X	HANDLE HOLDER RH STOIC BLACK	1	
11	56JL184X	STEP PILLION LH JL113014 SATIN BLACK	1	
12	56JL194X	STEP PILLION RH JL113016 SATIN BLACK	1	



Sr. No.	Part No.	Description	QTY.	Remarks
13	56JL254X	SHROUD INNER RH JL181020 SATIN BLACK	1	
14	56JL3S4X	STEP RIDER LH JL113009 SATIN BLACK	1	
15	56JF3T4X	STEP RIDER RH JF113006 SATIN BLACK	1	
16	56JL3X4X	STEP HOLDER LH (JL113057) SATIN BLACK	1	
17	56JL4J4X	STEP HOLDER PILLON LH JL113013 SATIN BLK	1	
18	56JL4K4X	STEP HOLDER PILLON RH JL113015 SATIN BLK	1	